



Domino Ax-Series **Codenet Protocol**

Ax150i

Ax350i

Ax550i

THIS PAGE INTENTIONALLY LEFT BLANK

DOMINO Ax-SERIES CODENET COMMUNICATIONS

This Codenet communications document, Domino Part No. EPT033760, specifies the protocol for communication between a remote controller and Ax-Series printers using Codenet protocol.

All rights reserved. No part of this publication may be reproduced, stored on a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior permission of Domino Printing Sciences plc.

Domino Printing Sciences plc. has a policy of continuous product improvement, the company therefore reserves the right to modify the specification contained in this user documentation without notice.

© Domino Printing Sciences plc. 2023.

For sales, service and inks please contact:

www.buydomino.com

www.domino-printing.com

Domino UK Ltd.

Bar Hill
Cambridge CB23 8TU
England
Tel: 01954 782551
Fax: 01954 782874

Domino North America

1290 Lakeside Drive
Gurnee IL.60031
U.S.A.
Tel: 847 244 2501
Fax: 847 244 1421

THIS PAGE INTENTIONALLY LEFT BLANK

CONTENTS

PART 1	DESCRIPTION
PART 2	SETUP
PART 3	PRINTER INITIALISATION COMMANDS
PART 4	PRINTER CONTROL COMMANDS
PART 5	PRINTER STATUS COMMANDS
PART 6	GLOBAL PRINTER FORMAT COMMANDS
PART 7	LABEL FORMATTING COMMANDS
PART 8	NEGATIVE ACKNOWLEDGEMENT ERROR CODES
PART 9	EXTENDED CODENET COMMANDS

AMENDMENT RECORD

Amendment	Date
All parts at Issue 1	August 2017
All parts at Issue 2	September 2017
All parts at Issue 3	February 2018
All parts at Issue 4	September 2019
All parts at Issue 5	December 2019
All parts at Issue 6	October 2020
All parts at Issue 7	March 2022
All parts at Issue 8	May 2022
All parts at Issue 9	March 2023
All parts at Issue 10	June 2023

PART 1 : DESCRIPTION

CONTENTS

	Page
DESCRIPTION	1-2
Form of Command	1-2
Send to Printer	1-2
Return from Printer	1-2
GENERAL	1-3
TYPES OF COMMANDS	1-4
Printer Commands	1-4
COMPATABILITY GUIDE	1-5
RETIRED COMMANDS	1-14
NEW COMMANDS IN DEVELOPMENT	1-15
HEX/ASCII CHARACTER LOOKUP TABLE	1-16

DESCRIPTION

Codenet is a communications protocol used in some of Domino's Continuous Ink Jet (CIJ) printers.

There are two versions of Codenet available:

Codenet 1 Used in the Domino Codebox, A-Series, A-Series plus and A-Series i-Tech printer ranges.

Codenet 2 Used in the Domino Ax-Series printer range. Codenet 2 is backwards compatible with Codenet 1 and includes additional 2 byte commands starting with 7E.

Form of Command

Note: The commands below are illustrated in both HEX and ASCII format.

Send to Printer

	ESC	Command ID	Parameter	EOT
ASCII	ESC			EOT
HEX	1B			04

Or

	ESC	Command ID	Parameter	Payload	EOT
ASCII	ESC			ESC xx ESC ~ xx	EOT
HEX	1B			1B xx 1B 7E xx	04

The payload can contain one or more embedded commands. Each starts with ESC (1B) or ESC ~ (1B7E) but has EOT (04) at the end. These can also have parameters. When the printer sees the EOT (04) it stops listening and all following bytes will be lost.

Return from Printer

ACK (06) or NAK (15) + Answer if applicable or Data if requested.

GENERAL

This section gives general information on the Codenet protocol described in this document.

- A positive acknowledgement (ACK) consists of a single Byte, (06).
- A negative acknowledgement (NAK) consists of four Bytes, (15xxx) where xxx is the type of error.
- The user can configure the response package length to Variable or Fixed in the printer's Ethernet setup menu:

Response Length = Variable	Response of Package Length means ACK is one byte (06 ₁₆), and NAK is four bytes (15 A B C). Where A, B and C represent a three-character Hex error code.
Response Length = Fixed	Response of Package Length means both ACK and NAK are four bytes (06303030 and 15 A B C). Where A, B and C represent a three-character Hex error code.

- Most commands come in two forms: a "setting" form that sends parameter information to the printer to set up a feature; or, a "query" form that asks the printer what the current settings of a parameter are.
- Most commands can be changed from the "setting" form to the "query" form by replacing the relevant parameter fields with a single "query" character, ? (3F).
- Many commands have either a head selection field or jet selection field. The head assignment field refers to the print head. For a printer with multiple ink jets, such as a duo printer, the head value 1 refers to the whole print head including both ink jets. The jet assignment field refers to individual ink jets.
- On a printer with a single print head, the head selection field should always be set to 1.
- The printer includes a feature where it will send an ACK/NAK at either of two points:

ON RECEIVED	This returns ACK as soon as the printer has received the data. Note, the data has not yet been validated as correct.
ON PROCESSED	This returns an ACK/NAK once the printer has processed the data.

For Printers Equipped with Duo Print Heads:

- The value of a head assignment field should always be 1.
- The jet assignment field of a command is 1 for ink jet 1, and 2 for ink jet 2. Ink jet 1 is on the left when looking at the front of the print head.

TYPES OF COMMANDS

Most commands are single byte, but some commands are double byte. Double byte commands are identified by the first byte in the command if:

- O (4F) = Extended = These were added when there were no more single bytes available to use.
- ~ (7E) = Codenet 2 = These will only work with the Ax-Series range of printers. NAK will be received from all other printer types.

The commands fall into two categories:

- Printer commands
- Label commands

Each category may have subcategories as described below.

Printer Commands

Initialisation Commands These commands perform functions such as requesting the printer's identity and setting up the real time clock, etc.

Print Control Commands These commands control operational features of the printer. For example, they identify which product detector to use for which print head. They also assign label stores to print heads and direct the loading of new print labels.

Printer Status Commands These commands allow the host system to control the unsolicited generation of status change reports and to obtain such reports on demand.

Global Format Commands These commands exert control over the orientation of printed labels and affect all characters printed.

Label Formatting Commands These commands are embedded within the text of stored print labels. Some of them affect the characters that follow until the end of the label, or until cancelled later in the label.

COMPATABILITY GUIDE

Command Name	Hex	ASCII	A-Series plus Compared to A-Series	A-Series i-Tech Compared to A-Series plus	Ax-Series Compared to A-Series i-Tech
Software reset	03	<ETX>	Same as A-Series	Not supported	Not supported
User Function Execute	2A	*	Not supported	Not supported	Not supported
Insert label script	2B	+	New	Same as A-Series plus	Same as A-Series i-Tech
Insert padding spaces	3C	<	New	Same as A-Series plus	Same as A-Series i-Tech
External label select	40	@	Same as A-Series	Different For A-Series, the only valid names are 001-063. For A-Series plus A100, the names 001-127 can be used. For all others, 001-255 can be used.	Same as A-Series i-Tech
Continuous printing	5B	[Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
External serial number reset, rollover and update	5D]	Same as A-Series	Same as A-Series plus	Supported but still under development
Auto invert	5C	\	Not supported	Not supported	Not supported
Read checksums	2141	!A	Not supported	Not supported	Not supported
2D Codes	7A	z	Different Has extra QR codes	Same as A-Series plus	Same as A-Series i-Tech
Insert updatable text field	7C		New	Same as A-Series plus	Same as A-Series i-Tech
Insert Language and Calendar Date/Time	7D	}	New	Same as A-Series plus	Same as A-Series i-Tech
Encoder frequency	7E40	~@	Not supported	Not supported	New

DESCRIPTION

Command Name	Hex	ASCII	A-Series plus Compared to A-Series	A-Series i-Tech Compared to A-Series plus	Ax-Series Compared to A-Series i-Tech
Encoder divide	7E41	~A	Not supported	Not supported	New
Source of encoder signal	7E42	~B	Not supported	Not supported	New
Userport Setup	7E43	~C	Not supported	Not supported	New but still under development
Get codenet version number	7E44	~D	Not supported	Not supported	New
Switch the label monitor updating on or off	7E45	~E	Not supported	Not supported	New
Set size of FiFo data buffer	7E46	~F	Not supported	Not supported	New but still under development
Connection count	7E48	~H	Not supported	Not supported	New
Reset ethernet connections	7E49	~I	Not supported	Not supported	New
Number of items in FiFo data buffer	7E50	~G	Not supported	Not supported	New
Reset FiFo Data Buffer	7E4A	~J	Not supported	Not supported	New
External data queue expired entries ID	7E4B	~K	Not supported	Not supported	New but still under development
External data queue expired entries persistent count	7E4C	~L	Not supported	Not supported	New but still under development
Global label invert	7E4D	~M	Not supported	Not supported	New
Insert thin space of one stroke	7E4E	~N	Not supported	Not supported	New
Status reporting mode	30	0	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Status request	31	1	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Printer identity	41	A	Different Printer Type "22" for A100 plus and "23" for A300.	Same as A-Series plus	Different Printer Type "30" for Ax-Series

DESCRIPTION

Command Name	Hex	ASCII	A-Series plus Compared to A-Series	A-Series i-Tech Compared to A-Series plus	Ax-Series Compared to A-Series i-Tech
Printer configuration	42	B	Different Max Msgs “255” for A300 plus and “127” for A100 plus. Baud rates 38400 (10), 57600 (11) and 115200 (12) are supported.	Same as A-Series plus.	Different No longer Sets. Can only Query
Set the printer real time clock	43	C	Different Years less than 2001 are not supported.	Same as A-Series plus	Same as A-Series i-Tech
Read/load month name table	44	D	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Read/load day name table	45	E	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Print go delay	46	F	Different “0000” & “0001” read as “0002”. Four or five digit delay is supported. Five digit delay is returned.	Same as A-Series plus	Same as A-Series i-Tech
Auto-repeat printing	47	G	Different This does not apply to the printed message. Instead, any messages subsequently created will include this setting.	Same as A-Series plus	Different Command retired.
Auto-reverse printing	48	H	Not supported	Not supported	Not supported

DESCRIPTION

Command Name	Hex	ASCII	A-Series plus Compared to A-Series	A-Series i-Tech Compared to A-Series plus	Ax-Series Compared to A-Series i-Tech
Printing acknowledgement flags	49	I	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Flight time compensation	4A	J	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Product detector assignment	4B	K	Not supported	Not supported	Not supported
Product detect signal level	4C	L	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Product detect signal persistence time	4D	M	Different Persistence can be two or five digits. A five digit persistence is returned.	Same as A-Series plus	Same as A-Series i-Tech
Print go	4E	N	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Get label from store and put it online	50	P	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Head enable	51	Q	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Clear all labels	52	R	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Store label with name as 3 digits	53	S	Different. Max number of labels is 127 for an A100 plus and 255 for other variants.	Same as A-Series plus	Same as A-Series i-Tech
Product counts	54	T	Different The “prints since power up” counter can be reset and queries provided if it is configured as “resettable counter 2”	Same as A-Series plus	Same as A-Series i-Tech

DESCRIPTION

Command Name	Hex	ASCII	A-Series plus Compared to A-Series	A-Series i-Tech Compared to A-Series plus	Ax-Series Compared to A-Series i-Tech
Read/Update Serial Number	55	U	Different For A-Series products, max number of labels is 063 For A-Series plus products, max number of labels is 127 for an A100 plus and 255 for other A-Series plus variants.	Same as A-Series plus.	Supported but still under development.
Stroke rate	56	V	Same as A-Series	Same as A-Series plus	Different. Returns the inverse of the UI value. e.g. 8000 will return 00125
Read modification level	57	W	Not supported	Not supported	Not used. Only implemented to maintain compatability with old controllers.
Load/Read Character Set	58	X	Not supported	Not supported	Not supported
Read/load alpha hours characters	59	Y	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Get software real-time clock	5A	Z	Same as A-Series	Different Command retired.	Not supported
Get current status	4F31	O1	Same as A-Series	Different Amber and red flashing now supported.	Same as A-Series i-Tech
Get current alert	4F32	O2	Not supported	Not supported	Not supported

DESCRIPTION

Command Name	Hex	ASCII	A-Series plus Compared to A-Series	A-Series i-Tech Compared to A-Series plus	Ax-Series Compared to A-Series i-Tech
Send data to FiFo buffer to fill an updatable text field	4F45	OE	New	Same as A-Series plus	Same as A-Series i-Tech
Print height	4F48	OH	Different Applies to all printed labels.	Same as A-Series plus	Same as A-Series i-Tech
Store Bitmap	4F4C	OL	New	Same as A-Series plus	Same as A-Series i-Tech
Store labels with variable length name from the label store and put online	4F4D	OM	New	Same as A-Series plus	Same as A-Series i-Tech
Retrieve a label with a variable length name from the label store and put online	4F4E	ON	New	Same as A-Series plus	Same as A-Series i-Tech
Download label without save	4F51	OQ	Different For A-Series products, max number of labels is 063. 127 for an A100 plus and 255 for other A-Series Plus variants.	Same as A-Series plus	Same as A-Series i-Tech
Sequence ink jet on and off	4F53	OS	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Configure FiFo buffer to receive external data	4F50	OP	New	Same as A-Series plus	Same as A-Series i-Tech
External data queue expired entries config	4F56	OV	Not supported	Not supported	New
Read liquid levels	79	y	Same as A-Series	Different Range = 0 to 8	Same as A-Series i-Tech
Global label reverse	61	a	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Global label bold	62	b	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech

DESCRIPTION

Command Name	Hex	ASCII	A-Series plus Compared to A-Series	A-Series i-Tech Compared to A-Series plus	Ax-Series Compared to A-Series i-Tech
Global label double space	63	c	Different Global command	Same as A-Series plus	Not supported
Barcode thickness ration	66	f	Different Supports module width, space to module width and wide to module width ratios.	Same as A-Series plus	Same as A-Series i-Tech
Global print format	67	g	Different For label bold, double space and reverse individual characters "NNN" is returned. Setting label bold, double space and reverse individual characters is ignored.	Same as A-Series plus	Different In Ax-Series, "Global Double Space Label" is currently not supported. Queries will always return N (4E).
Character reverse	64	d	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Character invert	65	e	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Change unicode page	68	h	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Select character	69	i	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech

DESCRIPTION

Command Name	Hex	ASCII	A-Series plus Compared to A-Series	A-Series i-Tech Compared to A-Series plus	Ax-Series Compared to A-Series i-Tech
Insert serial number	6A	j	Different For A-Series and A-Series plus A100 there is a limit of 1 serial number per label. For other A-Series plus models there is a limit of 2 serial numbers per label.	Same as A-Series plus	Different See “Notes” on page 7-11 .
Start bold character and logos	6B	k	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Select 2nd Character Font	6C	l	Not supported	Not supported	Not supported
Insert logo	6D	m	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Insert date/time	6E	n	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Offset clock	6F	o	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Insert shift code	70	p	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Insert barcode	71	q	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Line separator	72	r	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Double space label element	73	s	Not supported	Not supported	Different This command will stop and start double space printing.
Select 1st Character Font	74	t	Not supported	Not supported	Not supported

DESCRIPTION

Command Name	Hex	ASCII	A-Series plus Compared to A-Series	A-Series i-Tech Compared to A-Series plus	Ax-Series Compared to A-Series i-Tech
Set character height	75	u	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Stop bold characters	76	v	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Insert language date/time	77	w	Same as A-Series	Same as A-Series plus	Same as A-Series i-Tech
Insert bitmap	78	x	New	Same as A-Series plus	Same as A-Series i-Tech

RETIRED COMMANDS

Commands that are no longer implemented. The list is produced in this document so that commands are not reused. If you already use the commands with certain printer software then these can still be used. Take care when upgrading the printer software as the command may no longer be available.

Description	Command (Hex)	Command (ASCII)
Software Reset	03	ETX
User Function Execute	2A	*
Product Detector Assignment	4B	K
Auto-reverse Printing	48	H
Load/Read Character Set	58	X
Get Software Real Time Clock	5A	Z
Auto Invert Printing	5C	\
Select 2nd Character Font	6C	l
Select 1st Character Font	74	t
Read Checksums	2141	!A
Get Current Alert	4F32	O2

NEW COMMANDS IN DEVELOPMENT

The commands in the table below are new but still in development for the Ax-Series at the time of writing this document.

Description	HEX Command ID	ASCII Command ID
Read/Update Serial Number	55	U
External Serial Number Reset, Rollover and Update	5D]
Set Size of FiFo Data Buffer	7E46	~F
External Data Queue Expired Entries IDs	7E4B	~K
External Data Queue Expired Entries Persistent Count	7E4C	~L
Double Space Label Element	73	s

HEX/ASCII CHARACTER LOOKUP TABLE

Hex Character	ASCII Character	Description
0	NUL	Null
1	SOH	Start of heading
2	STX	Start of text
3	ETX	End of text
4	EOT	End of transmission
5	ENQ	End of transmission
6	ACK	Enquiry
7	BEL	Bell
8	BS	Backspace
9	TAB	Horizontal tab
A	LF	NL line feed, new line
B	VT	Vertical tab
C	FF	NP form feed, new page
D	CR	Carriage return
E	SO	Shift out
F	SI	Shift in
10	DLE	Data link escape
11	DC1	Device control 1
12	DC2	Device control 2
13	DC3	Device control 3
14	DC4	Device control 4
15	NAK	Negative acknowledge
16	SYN	Synchronous idle
17	ETB	End of transmission block
18	CAN	Cancel
19	EM	End of medium
1A	SUB	Substitute
1B	ESC	Escape
1C	FS	File separator
1D	GS	Group separator

DESCRIPTION

Hex Character	ASCII Character	Description
1E	RS	Record separator
1F	US	Unit separator
20	Space	Space
21	!	Exclamation mark symbol
22	"	Quotation mark symbol
23	#	Hash symbol
24	\$	Dollar symbol
25	%	Percent symbol
26	&	Ampersand symbol
27	'	Apostrophe symbol
28	(Left parenthesis symbol
29)	Right parenthesis symbol
2A	*	Asterisk symbol
2B	+	Plus symbol
2C	,	Comma symbol
2D	-	Hyphen-minus symbol
2E	.	Full stop symbol
2F	/	Solidus (forward slash) symbol
30	0	Number zero
31	1	Number one
32	2	Number two
33	3	Number 3
34	4	Number four
35	5	Number five
36	6	Number six
37	7	Number seven
38	8	Number eight
39	9	Number nine
3A	:	Colon symbol
3B	;	Semicolon symbol
3C	<	Less than symbol

DESCRIPTION

Hex Character	ASCII Character	Description
3D	=	Equals symbol
3E	>	Greater than symbol
3F	?	Question mark symbol
40	@	At symbol
41	A	Upper case letter A
42	B	Upper case letter B
43	C	Upper case letter C
44	D	Upper case letter D
45	E	Upper case letter E
46	F	Upper case letter F
47	G	Upper case letter G
48	H	Upper case letter H
49	I	Upper case letter I
4A	J	Upper case letter J
4B	K	Upper case letter K
4C	L	Upper case letter L
4D	M	Upper case letter M
4E	N	Upper case letter N
4F	O	Upper case letter O
50	P	Upper case letter P
51	Q	Upper case letter Q
52	R	Upper case letter R
53	S	Upper case letter S
54	T	Upper case letter T
55	U	Upper case letter U
56	V	Upper case letter V
57	W	Upper case letter W
58	X	Upper case letter X
59	Y	Upper case letter Y
5A	Z	Upper case letter Z
5B	[Left square bracket symbol

DESCRIPTION

Hex Character	ASCII Character	Description
5C	\	Reverse solidus (backward slash) symbol
5D]	Right square bracket symbol
5E	^	Circumflex accent symbol
5F	_	Underscore (low line) symbol
60	`	Grave accent symbol
61	a	Lower case letter a
62	b	Lower case letter b
63	c	Lower case letter c
64	d	Lower case letter d
65	e	Lower case letter e
66	f	Lower case letter f
67	g	Lower case letter g
68	h	Lower case letter h
69	i	Lower case letter i
6A	j	Lower case letter j
6B	k	Lower case letter k
6C	l	Lower case letter l
6D	m	Lower case letter m
6E	n	Lower case letter n
6F	o	Lower case letter o
70	p	Lower case letter p
71	q	Lower case letter q
72	r	Lower case letter r
73	s	Lower case letter s
74	t	Lower case letter t
75	u	Lower case letter u
76	v	Lower case letter v
77	w	Lower case letter w
78	x	Lower case letter x
79	y	Lower case letter y
7A	z	Lower case letter z

DESCRIPTION

Hex Character	ASCII Character	Description
7B	{	Left curly bracket
7C		Vertical bar symbol
7D	}	Right curly bracket
7E	~	Tilde symbol
7F	DEL	Delete

PART 2 : SETUP

CONTENTS

	Page
SETUP	2-3
CONNECTION VIA RS232 INTERFACE	2-3
RS232 Connector Description	2-3
RS232 Codenet Protocol Settings	2-4
Ethernet TCP/IP Codenet Protocol Settings	2-8

SETUP

THIS PAGE INTENTIONALLY LEFT BLANK

SETUP

Depending on the hardware packs with which the printer is equipped, either RS232 or an Ethernet TCP/IP interface can be used to send Codenet data packets to the printer.

This section describes how to connect a controller to the printer via ether RS232 or an Ethernet TCP/IP interface.

CONNECTION VIA RS232 INTERFACE

To enable Codenet communication with an Ax-Series printer via RS232, the printer must be equipped with an RS232 connectivity pack. The RS232 pack adds an 8-Way RS232 port to the printer cabinet.

RS232 Connector Description

The RS232 connector provides external RS232 level serial connection to user equipment.


Connector type: 8-way DIN plug IEC60160-9

Mating cable connector type: 8-way DIN socket

The RS232 connector pin description is shown below.

Table 1: J10 Pin Description

Pin	Signal	Description
1	RS232_DCD	Data Carrier Detect
2	RS232_TXD	Transmit Data Output
3	RS232_RXD	Receive Data Input
4	RS232_DSR	Data Set Ready Input
5	0V	Signal GND
6	RS232_DTR	Data Terminal Ready Output
7	RS232_CTS	Clear To Send Input
8	RS232_RTS	Request To Send Output
Shell	NC	EMC_GND via panel mounting



*8-Way RS232 Port Connections
(External View)*

RS232 Codenet Protocol Settings

The settings described below are used to set the protocol type used for external communications.

To configure the protocol settings for Codenet via RS232:

- (1) On the printer's TouchPanel select *Home > Setup > Printer network > Protocol settings*.
- (2) Select the *Protocol Setting* drop down setting and select *Codenet*.
- (3) Un-tick the *Protocol enabled* tick box.
- (4) Select the *Protocol Mode* drop down setting and select *Serial*.
- (5) Select the *Serial Com* setting and select either:

Table 2: Serial Com Settings

Setting Name	Description
COM1	For communication via the RS232 Socket (if fitted).
COM2	For communication via the 37-Way Socket (if fitted).

- (6) Select *Advanced*.
- (7) The settings described in the table below can be set using the drop down boxes.

Table 3: Advanced Serial Settings

Setting Name	Description
Baud rate	Select the baud rate between the printer and the device the printer is connected to. Range: 1200-115200 Default setting: 9600
Data bits	Select the number of data bits in each character. Default setting: 8
Parity	Select the type of parity bit that will be expected. A parity bit is an extra data bit that will be sent with each data character to detect errors in the transmission. Default setting: No parity <i>No parity</i> - No parity bit will be expected. <i>Odd</i> - An odd parity bit will be expected. <i>Even</i> - An even parity bit will be expected. <i>Mark</i> - The parity bit will always be 1 but will not be used. <i>Space</i> - The parity bit will always be 0 but will not be used.
Stop bits	Select the number of stop bits that will be sent at the end of each character to enable the detection of the end of the character. Default setting: 1

Table 3: Advanced Serial Settings

Setting Name	Description
Flow control	<p>Select the type of handshake signal that will be used to pause and resume the transmission of data. Default setting: RTS/CTS</p> <p><i>Note:</i> When the flow control state becomes <XOFF> from the printer, or NOT RTS, the printer will buffer characters received for processing up to 32. Any further characters will be discarded. Even though the printer requires data entry to be suspended, the printer will accept and process flow control state change requests or change in CTS state, and the software reset command <SW_RESET></p> <p>None - Flow control will not be enabled. None, DTR Enabled -</p> <ul style="list-style-type: none"> • The DTR output line will be asserted (+12V) whenever the printer is ready to receive data. • The DTR output line will be de-asserted (-12V) whenever the printer is not ready for data entry. <p>DTR/DSR -</p> <ul style="list-style-type: none"> • The DTR output line will be asserted (+12V) whenever the printer is ready to receive data. • The DTR output line will be de-asserted (-12V) whenever the printer is not ready for data entry. • Whenever the DSR input line is asserted (+12V), the printer will be enabled for the sending of data. • Whenever the DSR input line is de-asserted (-12V), the printer will suspend data output. <p>RTS/CTS -</p> <ul style="list-style-type: none"> • The RTS output line will be asserted (+12V) whenever the printer is ready to receive data. • The RTS output line will be de-asserted (-12V) whenever the printer is not ready for data entry. • Whenever the CTS input line is asserted (+12V), the printer will be enabled for the sending of data. • Whenever the CTS input line is de-asserted (-12V), the printer will suspend data output. <p>XOn/XOff - When XOn/Xoff is selected, CTS and RTS signals must not be connected.</p> <ul style="list-style-type: none"> • The printer will send a single ASCII <XOFF> (013) character whenever it requires data entry to be suspended. • The printer will send a single ASCII (011) character whenever it becomes ready to receive data. • Whenever the printer receives an <XOFF> character it will suspend its data output. Transmission from the printer will be enabled whenever it receives an character.

(8) Select Save.

(9) The protocol settings described in the table below can also be set. After the settings have been defined, tick the *Protocol Enabled* tick box.

Table 4: RS232 Codenet Protocol Settings

Setting Name	Description
Response Length	<p>Define the length of the response data package:</p> <p><i>Variable</i> - ACK is one byte (06₁₆), and NAK is four bytes (15, A, B, C). Where A, B and C represent a three character Hex error code.</p> <p><i>Fixed</i> - Both ACK and NAK are four bytes (06303030 and 15 A B C). Where A, B and C represent a three character Hex error code.</p>
Send Response	<p>Define when a response to a data packet will be sent from the printer.</p> <p><i>On Processed</i> - The ACK or NAK will be sent when the printer has processed a data packet.</p> <p><i>On Received</i> - An ACK will be sent as soon as the printer receives a data packet. Note, the data has not yet been validated as correct.</p>
LED State	<p>This setting allows the LEDs on the printer cabinet to mimic the behaviour of different printer types. This is useful if a different printer type is replaced with an Ax-Series printer.</p> <p><i>Standard</i> - The LEDs on the printer cabinet will mimic the behaviour of A-Series i-Tech and A-Series plus printers.</p> <p><i>Green + Flash</i> - The LEDs on the printer cabinet will mimic the behaviour of an A-Series classic printer.</p>
Printer ID	<p>This setting allows the printer to respond using the ID of older printer types. This is useful if an older printer type is replaced with an Ax-Series printer, as the controller may be expecting a different response value.</p> <p>00 = Codebox 01 = Solo 02 = Solo Twin Head 03 = A300 04-19 = Not Allocated 20 = Macrojet 21 = Casecoder 22 = A-Series plus A100 23 = A-Series plus A300 24 = A-Series plus Duo 25-29 = Not Allocated 30 = Ax-Series 31 - 99 = Not Allocated</p>
Label Format	<p>Select which label format/raster will be used when a data packet containing a label design is sent to the printer.</p>
Backward Compatible	<p>This tick box currently has no function. It may be removed in a later software update.</p>

SETUP

(10) Tick the *Protocol enabled* tick box.

(11) To save the new settings, select *Home > Setup > Production line setup > Power options > Restart* and wait for the printer to restart.

End of procedure.

Ethernet TCP/IP Codenet Protocol Settings

The settings described below are used to set the protocol type used for external communications.

To configure the protocol settings for Codenet via Ethernet TCP/IP:

- (1) On the printer's TouchPanel select *Home > Setup > Printer network > Protocol settings*.
- (2) Select the *Protocol Setting* drop down setting and select *Codenet*.
- (3) Un-tick the Protocol enabled tickbox.
- (4) Select the *Protocol Mode* drop down setting and select *TCP*.
- (5) The settings described in the table below can be set:

Table 5: Ethernet TCP/IP Codenet Protocol Settings

Setting Name	Description
TCP Port	Define the port that will be used for codenet communication. <i>Four TCP ports are available for Ethernet TCP/IP communication: 7000, 7001, 7002 and 7004.</i> Default setting: 7000
Response Length	Define the length of the response data package: <i>Variable</i> - ACK is one byte (06 ₁₆), and NAK is four bytes (15, A, B, C). Where A, B and C represent a three character Hex error code. <i>Fixed</i> - Both ACK and NAK are four bytes (06303030 and 15 A B C). Where A, B and C represent a three character Hex error code.
Send Response	Define when a response to a data packet will be sent from the printer. <i>On Processed</i> - The ACK or NAK will be sent when the printer has processed a data packet. <i>On Received</i> - An ACK will be sent as soon as the printer receives a data packet. Note, the data has not yet been validated as correct.
LED State	This setting allows the LEDs on the printer cabinet to mimic the behaviour of different printer types. This is useful if a different printer type is replaced with an Ax-Series printer. <i>Standard</i> - The LEDs on the printer cabinet will mimic the behaviour of A-Series i-Tech and A-Series plus printers. <i>Green + Flash</i> - The LEDs on the printer cabinet will mimic the behaviour of an A-Series classic printer.

Table 5: Ethernet TCP/IP Codenet Protocol Settings

Setting Name	Description
Printer ID	<p>This setting allows the printer to respond using the ID of older printer types. This is useful if an older printer type is replaced with an Ax-Series printer, as the controller may be expecting a different response value.</p> <p>00 = Codebox 01 = Solo 02 = Solo Twin Head 03 = A300 04-19 = Not Allocated 20 = Macrojet 21 = Casecoder 22 = A-Series plus A100 23 = A-Series plus A300 24 = A-Series plus Duo 25-29 = Not Allocated 30 = Ax-Series 31 - 99 = Not Allocated</p>
Label Format	<p>Select which label format/raster will be used when a data packet containing a label design is sent to the printer.</p>
Backward Compatible	<p>This tick box currently has no function. It may be removed in a later software update.</p>

(6) Tick the *Protocol enabled* tick box.

(7) To save the new settings, select *Home > Setup > Production line setup > Power options > Restart* and wait for the printer to restart.

End of procedure.

THIS PAGE INTENTIONALLY LEFT BLANK

PART 3 : PRINTER INITIALISATION COMMANDS

CONTENTS

	Page
PRINTER INITIALISATION COMMANDS	3-3
Printer Identity – 'A' 41h	3-3
Query String Format	3-3
Response to Query	3-3
Examples of Usage.....	3-4
Printer ID on User Interface	3-4
Query and Response String Examples	3-5
Request Printer Configuration – 'B' 42h	3-6
Query String Format	3-6
Set the Printer Real Time Clock – 'C' 43h	3-8
Set String Format	3-8
Response to Set	3-8
Query String Format:	3-8
Response to Query	3-8
Set and Response String Examples	3-9
Query and Response String Examples	3-9
Read/Load Month Name Table – 'D' 44h	3-10
Set String Format	3-10
Response to Set	3-11
Query String Format	3-11
Response to Query	3-11
Set and Response String Examples	3-11
Query and Response String Examples	3-11
Read/Load Day Name Table – 'E' 45h	3-12
Set String Format	3-12
Response to Set	3-12
NAK (15) = Negative	3-12
Query String Format	3-12
Response to Query	3-13
Set and Response String Examples	3-13
Query and Response String Examples	3-13
Read/Load Alpha Hours Characters – 'Y' 59h	3-14
Set String Format	3-14
Response to Set	3-16
Query String Format	3-16
Response to Query	3-16
Set and Response String Examples	3-16
Query and Response String Examples	3-16
Encoder Frequency – '~@' 7Eh 40h	3-17
Set String Format	3-17
Response to Set	3-17
Query String Format	3-17
Response to Query	3-17
Set and Response String Examples	3-17
Query and Response String Examples.....	3-18
Encoder Divide – '~A' 7Eh 41h	3-19
Set String Format	3-19

PRINTER INITIALISATION COMMANDS

Response to Set	3-19
Query String Format	3-19
Response to Query	3-19
Set and Response String Examples	3-19
Query and Response String Examples.....	3-20
Source of Encoder Signal – '~B' 7Eh 42h	3-21
Set String Format	3-21
Response to Set	3-21
Query String Format	3-21
Response to Query	3-21
Set and Response String Examples	3-21
Query and Response String Examples.....	3-22
Get Codenet Version Number – '~D' 7Eh 44h	3-23
Query String Format	3-23
Response to Query	3-23
Query and Response String Examples	3-23

PRINTER INITIALISATION COMMANDS

Printer Identity – 'A' 41_h

This command instructs the printer to return it's variant type. It should be the first command sent to establish the communications link.

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	A	?	EOT
HEX	1B	41	3F	04

Response to Query

	ESC	Command ID	Printer Type	SBC Software Part Number	SBC Software Issue Number	Codenet ID	EOT
ASCII	ESC	A	00 to 99	00000 to 99999	00 to 99	00	EOT
HEX	1B	41	3030 to 3939	3030303030 to 3939393939	3030 to 3939	3030	04

Printer Type: Two bytes specifying the printer type.
 00 (3030) = Codebox
 01 (3031) = Solo
 02 (3032) = Solo Twin Head
 03 (3033) = A300
 04-19 (3034-3139) = Not Allowed
 20 (3230) = Macrojet
 21(3231) = Casecoder
 22 (3232) = A-Series plus A100
 23 (3233) = A-Series plus A300
 24 (3234) = A-Series plus Duo
 25-29 (3235-3239) = Not Allocated
 30 (3330) = Ax-Series
 31-39 (3331-3339) = Not Allocated
 40 (3430) = Jx-Series
 41-99 (3431-3939) = Not Allocated

Firmware Part: Five bytes that specify the SBC software part number.

Firmware Issue: Two bytes that specify the SBC software issue number.

Codenet ID: Two byte Codenet identity. No longer used. Always set to 00 (3030).

Examples of Usage

To printer:


	ESC	Command ID	Payload	EOT
ASCII	ESC	A	?	EOT
HEX	1B	41	3F	04

From printer:

	ESC	Command ID	Printer Type		Build Part Number					Firmware		Not Used		EOT
ASCII	ESC	A	0	3	5	6	0	0	6	0	1	0	0	EOT
HEX	1B	41	30	33	35	36	30	30	36	30	31	30	30	04

Printer ID on User Interface

The printer type value can be changed so the printer can mimic other printer types. This is used when replacing an older printer and the controller asks for this information and is expecting a set value. As the controller is old, it cannot be updated with the new values. The Printer ID value can be changed by selecting *Home > Setup > Printer Network > Protocol settings*.



Printer ID Setting

- Notes: (1) For an Ax-Series the SBC Part Number and SBC Version Number are not used. They are static data and will always return the same value.
- (2) The Printer Type is dynamic and will return the value set in the UI.

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 41 3F 04

Response from printer: 1B 41 33 30 35 36 30 36 30 36 37 30 31 30 30 04

Request Printer Configuration – 'B' 42_h

This command is normally used to request the ink printer to return its configuration data. It should be sent in order to determine the commands which are applicable to the particular installation. It may also be used as to alter certain configuration values marked with * (Baud Rate and Flow Control) – although the other fields will still need to be specified. Such changes will take effect on completion of the command acknowledgement.

Do not use this command to alter the printer's configuration. Although an acknowledgement will be received, your change request will have no effect. This command is present for backwards compatibility only.

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	B	?	EOT
HEX	1B	42	3F	04

Response to Query

	ESC	Command ID	Number of Jets	Print Head Configuration	Max Number of Labels
ASCII	ESC	B	1 or 2	000000000000 00000 to 07070707070 70707	000 to 255
HEX	1B	42	31 or 32	30303030303 03030 to 37373737373 73737	303030 to 323535

Max Label Length	Barcode Format	Baud Rate	Flow Control	Number of User App Commands	EOT
000 to 255	00 to 04	00 to 11	48 or 53	30	EOT
303030 to 323535	3030 to 3034	3030 to 3131	3438 or 3533	3330	04

PRINTER INITIALISATION COMMANDS

Number of Jets:	One digit, number of ink jets.
Print Head Configuration:	Four pairs of configuration data for ink jets one to four. 00 (3030) = head not present 01 (3031) = single line 02 (3032) = twin line 03 (3033) = twin line + large 04 (3034) = triple line 05 (3035) = triple line mixed 06 (3036) = four line 07 (3037) = 9 drop proportional
Max Number of Labels:	<i>Note: Ax-Series printers are capable of more than 255 labels. However, for backwards compatibility, the maximum response is set to 255.</i> Range 000 to 255 (303030 to 323535)
Max Label Length:	<i>Note: Ax-Series printers are capable of maximum label lengths greater than 255. However, for backwards compatibility, the maximum response is set to 255.</i> Range 000 to 255 (303030 to 323535)
Barcode Format:	<i>Note: Currently, always returns 00 (3030) for backwards compatibility.</i> 00 (3030) = none 01 (3031) = code 39 02 (3032) = interleaved 2 of 5 03 (3033) = not used 04 (3034) = EAN/UPC
Baud Rate:	00 (3030) = 75 01 (3031) = 150 02 (3032) = 300 03 (3033) = 600 04 (3034) = 1200 05 (3035) = 2400 06 (3036) = 4800 07 (3037) = 9600 08 (3038) = 19200 09 (3039) = 110 10 (3130) = 38400 11 (3131) = 57600
Flow Control:	H (48) = RTS/CTS S (53) = XON/XOFF
Number of User Application Commands:	0 (30) = Default, always returns this value.

Set the Printer Real Time Clock – 'C' 43_h

This command sets the printer's internal real time clock to the date and time given in the command parameters. Range is from 2001 to 2038. The Ax-Series does not use daylight savings. Therefore, the time returned may be one hour different to the actual time.

Set String Format

	ESC	Command ID	Century	Year of Century	Month of Year
ASCII	ESC	C	20 and above	00 to 99	01 to 12
HEX	1B	43	3230 and above	3030 to 3939	3031 to 3132

Day of Month	Not Used	Hour of Day	Minute of Hour	Second of Minute	EOT
01 to 31	Always set to 00	00 to 23	00 to 59	00 to 59	EOT
3031 to 3331	Always set to 30	3030 to 3233	3030 to 3539	3030 to 3539	04

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format:

	ESC	Command ID	Query Command	EOT
ASCII	ESC	C	?	EOT
HEX	1B	43	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the printer's real time clock to May 24th 2016 at 12:19:16.

Sent to printer: 1B 43 32 30 31 36 30 35 32 34 30 30 31 32 31 39 31 36 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 43 3F 04

Response from printer: 1B 43 32 30 31 37 30 31 31 39 30 30 31 34 33 37 34 32 04

Read/Load Month Name Table – 'D' 44_h

This command allows the text strings used for month name entries to be set up or returned to the terminal.

Set String Format

	ESC	Command ID	Month 1 of Year	Month 2 of Year	Month 3 of Year
ASCII	ESC	D	AAA to zzz	AAA to zzz	AAA to zzz
HEX	1B	44	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A

Month 4 of Year	Month 5 of Year	Month 6 of Year	Month 7 of Year	Month 8 of Year
AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz
414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A

Month 9 of Year	Month 10 of Year	Month 11 of Year	Month 12 of Year	EOT
AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz	EOT
414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	04

- Month 1 of year: Default = JAN (4A414E)
- Month 2 of year: Default = FEB (464542)
- Month 3 of year: Default = MAR (4D4152)
- Month 4 of year: Default = APR (41552)
- Month 5 of year: Default = MAY (4D4159)
- Month 6 of year: Default = JUN (4A554E)
- Month 7 of year: Default = JUL (4A554C)
- Month 8 of year: Default = AUG (415557)
- Month 9 of year: Default = SEP (534550)
- Month 10 of year: Default = OCT (4F4354)
- Month 11 of year: Default = NOV (4E4F56)
- Month 12 of year: Default = DEC (444543)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	D	?	EOT
HEX	1B	44	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the printer's month names to the default values.

Sent to printer: 1B 44 4A 41 4E 46 45 42 4D 41 52 41 50 52 4D 41 59 4A 55 4E 4A
55 4C 41 55 47 53 45 50 4F 43 54 4E 4F 56 44 45 43 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 44 3F 04

Response from printer: 1B 44 4A 41 4E 46 45 42 4D 41 52 41 50 52 4D 41 59 4A 55 4E 4A
55 4C 41 55 47 53 45 50 4F 43 54 4E 4F 56 44 45 43 04

Read/Load Day Name Table – 'E' 45_h

This command allows the text strings used for day name entries to be set up or returned to the terminal.

Set String Format

	ESC	Command ID	Day 1 of Week	Day 2 of Week	Day 3 of Week
ASCII	ESC	E	AAA to zzz	AAA to zzz	AAA to zzz
HEX	1B	45	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A

Day 4 of Week	Day 5 of Week	Day 6 of Week	Day 7 of Week	EOT
AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz	EOT
414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	04

Day 1 of Week: Default = MON (6D6F6E)

Day 2 of Week: Default = TUE (545545)

Day 3 of Week: Default = WED (574544)

Day 4 of Week: Default = THU (544855)

Day 5 of Week: Default = FRI (465249)

Day 6 of Week: Default = SAT (534154)

Day 7 of Week: Default = SUN (53554E)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	E	?	EOT
HEX	1B	45	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the printer's day names to the default values.

Sent to printer: 1B 45 4D 4F 4E 54 55 45 57 45 44 54 48 55 46 52 49 53 41 54 53
55 4E 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 45 3F 04

Response from printer: 1B 45 4D 4F 4E 54 55 45 57 45 44 54 48 55 46 52 49 53 41 54 53
55 4E 04

Read/Load Alpha Hours Characters – 'Y' 59_h

This command allows the 24 characters used with the Alpha Hour option to be set up or returned to the terminal.

Set String Format

	ESC	Command ID	Hour 1 of Day	Hour 2 of Day	Hour 3 of Day
ASCII	ESC	Y	AAA to zzz	AAA to zzz	AAA to zzz
HEX	1B	59	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A

Hour 4 of Day	Hour 5 of Day	Hour 6 of Day	Hour 7 of Day	Hour 8 of Day
AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz
414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A

Hour 9 of Day	Hour 10 of Day	Hour 11 of Day	Hour 12 of Day	Hour 13 of Day
AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz
414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A

Hour 14 of Day	Hour 15 of Day	Hour 16 of Day	Hour 17 of Day	Hour 18 of Day
AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz
414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A

Hour 19 of Day	Hour 20 of Day	Hour 21 of Day	Hour 22 of Day	Hour 23 of Day
AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz	AAA to zzz
414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A	414141 to 7A7A7A

Hour 24 of Day	EOT
AAA to zzz	EOT
414141 to 7A7A7A	04

PRINTER INITIALISATION COMMANDS

Hour 1 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is A
Hour 2 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is B
Hour 3 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is C
Hour 4 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is D
Hour 5 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is E
Hour 6 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is F
Hour 7 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is G
Hour 8 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is H
Hour 9 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is J
Hour 10 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is K
Hour 11 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is L
Hour 12 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is M
Hour 13 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is N
Hour 14 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is P
Hour 15 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is Q
Hour 16 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is R
Hour 17 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is S
Hour 18 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is T
Hour 19 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is U
Hour 20 of Day:	1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20). Default is V

PRINTER INITIALISATION COMMANDS

- Hour 21 of Day: 1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20).
Default is W
- Hour 22 of Day: 1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20).
Default is X
- Hour 23 of Day: 1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20).
Default is Y
- Hour 24 of Day: 1 Byte, A to z (41 to 7a), 1 to 9 (31 to 39) or <space> (20).
Default is Z

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	Y	?	EOT
HEX	1B	59	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the printer's alpha hour characters to the default values.

Sent to printer: 1B 59 41 42 43 44 45 46 47 48 4A 4B 4C 4D 4E 50 51 52 53 54 55
56 57 58 59 5A 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated below.

Sent to printer: 1B 59 3F 04

Response from printer: 1B 59 41 42 43 44 45 46 47 48 4A 4B 4C 4D 4E 50 51 52 53 54 55
56 57 58 59 5A 04

Encoder Frequency – '~@' 7E_h 40_h

This Command will Get and Set the stroke rate of the internal encoder.

The internal print frequency parameter is a division factor for a Timer/Counter in the original interface. The encoder frequency that is sent to the printer is calculated using the formula below:

$$\text{Frequency} = 11.0592 \text{ MHz} / (2 * (1 + \text{Parameter}) * 255)$$

Set String Format

	ESC	Command ID	Internal Shaft Encoder Stroke Rate	EOT
ASCII	ESC	~@	NUL NUL to ÿÿ	EOT
HEX	1B	7E40	0000 to FFFF	04

Internal Encoder Stroke Rate: The current value of the stroke rate of the internal shaft encoder in Hz.
2 Bytes, NUL NUL to ÿÿ (0000 to FFFF)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	~@	?	EOT
HEX	1B	7E40	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the stroke rate of the printer's internal encoder to 0465.

Sent to printer: 1B 7E 40 30 34 36 35 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated below.

Sent to printer: 1B 7E 40 3F 04

Response from printer: 1B 7E 40 30 34 36 35 04

Encoder Divide – '~A' 7E_h 41_h

This command will get and set the divide value that is used to scale down the external encoder frequency.

Set String Format

	ESC	Command ID	Encoder Divide Factor	EOT
ASCII	ESC	~A	NUL NUL NUL NUL to ÿÿÿÿ	EOT
HEX	1B	7E41	00000000 to FFFFFFFF	04

Encoder Divide: Four Byte encoder signal frequency divide factor.
NUL NUL NUL NUL to ÿ ÿ ÿ ÿ (00 00 00 00 to FF FF FF FF) MSB first.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	~A	?	EOT
HEX	1B	7E41	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the printer's encoder divide value to 0001.

Sent to printer: 1B 7E 41 30 30 30 31 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated below.

Sent to printer: 1B 7E 41 3F 04

Response from printer: 1B 7E 41 30 30 30 31 04

Source of Encoder Signal – '~B' 7E_h 42_h

This command will set the source of the encoder.

Set String Format

	ESC	Command ID	Source of Encoder Signal	EOT
ASCII	ESC	~B	0 or 1	EOT
HEX	1B	7E42	30 or 31	04

Source of Encoder Signal: Single byte to set the source of the encoder signal.
 0 (30) = Internal
 1 (31) = External

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	~B	?	EOT
HEX	1B	7E42	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the printer's encoder source to internal.

Sent to printer: 1B 7E 42 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated below.

Sent to printer: 1B 7E 42 3F 04

Response from printer: 1B 7E 42 30 04

Get Codenet Version Number – '~D' 7E_h 44_h

This command gets the current version of Codenet.

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	~D	?	EOT
HEX	1B	7E44	3F	04

Response to Query

	ESC	Command ID	Codenet Version	EOT
ASCII	ESC	~D	0000 to 9999	EOT
HEX	1B	7E44	30303030 to 39393939	04

Codenet Version: Four Bytes displaying the Codenet version.
0000 to 9999 (30303030 to 39393939)

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated below.

Sent to printer: 1B 7E 44 3F 04

Response from printer: 1B 7E 44 30 31 30 30 04

THIS PAGE INTENTIONALLY LEFT BLANK

PART 4 : PRINTER CONTROL COMMANDS

CONTENTS

	Page
PRINTER CONTROL COMMANDS	4-5
Print Go Delay – 'F' 46h	4-5
Set String Format	4-5
Response to Set	4-5
NAK (15) = Negative	4-5
Query String Format	4-5
Response to Query	4-5
Set and Response String Examples	4-6
Query and Response String Examples	4-6
Auto-repeat Printing – 'G' 47h	4-7
Set String Format	4-7
Response to Set	4-7
NAK (15) = Negative	4-7
Query String Format	4-7
Response to Query	4-7
Set and Response String Examples	4-8
Query and Response String Examples	4-8
Printing Acknowledgement Flags – 'I' 49h	4-9
Set String Format	4-9
Response to Set	4-9
Query String Format	4-9
Response to Query	4-10
Set and Response String Examples	4-10
Query and Response String Examples	4-10
Flight Time Compensation – 'J' 4Ah	4-11
Set String Format	4-11
Response to Set	4-11
Query String Format	4-11
Response to Query	4-11
Set and Response String Examples	4-12
Query and Response String Examples	4-12
Product Detect Signal Level – 'L' 4Ch	4-13
Set String Format	4-13
Response to Set	4-13
Query String Format	4-13
Response to Query	4-13
Set and Response String Examples	4-14
Query and Response String Examples	4-14
Product Detect Signal Persistence Time – 'M' 4Dh	4-15
Set String Format	4-15
Response to Set	4-15
NAK (15) = Negative	4-15
Query String Format	4-15
Response to Query	4-15
Set and Response String Examples	4-16
Query and Response String Examples	4-16
Print Go – 'N' 4Eh	4-17

PRINTER CONTROL COMMANDS

Set String Format	4-17
Response to Set	4-17
Set and Response String Examples	4-17
Get label from store and put online – 'P' 50h	4-18
Set String Format	4-18
Response to Set	4-18
NAK (15) = Negative	4-18
Query String Format	4-18
Response to Query	4-18
Set and Response String Examples	4-18
Query and Response String Examples.....	4-19
Head Enable – 'Q' 51h	4-20
Set String Format	4-20
Response to Set	4-20
Query String Format	4-20
Response to Query	4-20
Set and Response String Examples.....	4-21
Query and Response String Examples	4-21
Clear All Labels – 'R' 52h	4-22
Set String Format	4-22
Response to Set	4-22
Set and Response String Examples	4-22
Store Label with Name as 3 digits – 'S' 53h	4-23
Set String Format	4-23
Response to Set	4-23
Query String Format	4-23
Response to Query	4-24
Worked Examples.....	4-25
Set and Response String Examples	4-28
Query and Response String Examples	4-28
Product Counts – 'T' 54h	4-29
Set String Format	4-29
Response to Set	4-29
NAK (15) = Negative	4-29
Query String Format	4-29
Response to Query.....	4-30
Set and Response String Examples	4-30
Query and Response String Examples	4-30
Stroke Rate – 'V' 56h	4-31
Query String Format	4-31
Response to Query	4-31
Query and Response String Examples	4-31
Read Modification Level – 'W' 57h	4-32
Query String Format	4-32
Response to Query	4-32
Query and Response String Examples	4-32
External Label Select – '@' 40h	4-33
Set String Format	4-33
Response to Set	4-33
Query String Format	4-33
Response to Query	4-33
Set and Response String Examples.....	4-34
Query and Response String Examples	4-34

PRINTER CONTROL COMMANDS

Continuous Printing – '[' 5Bh	4-35
Set String Format	4-35
Response to Set	4-35
Query String Format	4-35
Response to Query	4-35
Set and Response String Examples	4-36
Query and Response String Examples	4-36
Switch Label Monitor Updating On/Off – '~E' 7Eh 45h	4-37
Set String Format	4-37
Response to Set	4-37
Query String Format	4-37
Response to Query	4-37
Set and Response String Examples	4-37
Query and Response String Examples	4-38
Number of items in the FIFO Data Buffer – '~G' 7Eh 47h	4-39
Query String Format	4-39
Response to Query	4-39
Query and Response String Examples	4-39
Number of items in the FIFO Data Buffer – '~P' 7Eh 50h	4-40
Query String Format	4-40
Response to Query	4-40
Query and Response String Examples	4-40
Connection Count – '~H' 7Eh 48h	4-41
Query String Format	4-41
Response to Query	4-41
Query and Response String Examples	4-41
Reset Ethernet Connections – '~I' 7Eh 49h	4-42
Set String Format	4-42
Response to Set	4-42
Set and Response String Examples	4-42
Reset FIFO Data Buffer – '~J' 7Eh 4Ah	4-43
Set String Format	4-43
Response to Set	4-43
Set and Response String Examples	4-43

THIS PAGE INTENTIONALLY LEFT BLANK

PRINTER CONTROL COMMANDS

Print Go Delay – 'F' 46_h

This command will set the delay between receiving a print go signal and starting printing. The delay is measured in stroke go pulses.

Notes: (1) Delay values of 0 and 1 are interpreted as 2.

(2) The Delay Value for Ax-Series printers is 5 digits and ranges from 00000 (3030303030) to 65535 (3635353335) as shown below. Older non Ax-Series printers (depending on the type in use) could be 4 digits and in the range of 0000 (30303030) to 9999 (39393939). Ax-Series has support for both 4 and 5 digit Delay Value set formats.

Set String Format

	ESC	Command ID	Head Select	Delay Value	EOT
ASCII	ESC	F	1	00000 to 65535	EOT
HEX	1B	46	31	3030303030 to 3635353335	04

Head Select: 1 byte print head selection. This is always 1 (31) for an Ax-Series printer.

Delay Value: 4 byte delay value, 0000 to 9999 (30303030 to 39393939)
Default value is 0 0 0 0 (30 30 30 30)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	F	1	?	EOT
HEX	1B	46	31	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the print go delay value to 00132.

Sent to printer: 1B 46 31 30 30 31 33 32 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 46 3F 04

Response from printer: 1B 46 31 30 30 31 33 32 04

Auto-repeat Printing – 'G' 47_h

This command specifies the number of additional times that a label is printed for each print-go command signal, provided that the signal remains in the active state. A repeat number of 99 (3939) signifies continuous printing while the print-go signal is active.

Notes: (1) Set is 4 bytes but query is 5 bytes.

(2) **IMPORTANT:** Changes applied with the SET command will only be applied to labels created afterwards (e.g. using the 0x53 - 'S' - command). Any labels created before the new settings were applied will not be affected.

Set String Format

	ESC	Command ID	Head Select	Repeat Number	Repeat Pitch	EOT
ASCII	ESC	G	1	00 to 99	0000 to 9999	EOT
HEX	1B	47	31	3030 to 3939	30303030 to 39393939	04

Head Select: 1 byte print head selection. This will always be 1 (31) for an Ax-Series.

Repeat Number: 2 byte repeat number 00 to 99 (3030 to 3939)
 99 (3939) = continuous
 00 (3030) = default

Repeat Pitch: 4 byte repeat pitch.
 0000 to 9999 (30303030 to 39393939) strokes
 0000 (30303030) = default

Note: Pitch values of 0 and 1 are interpreted as 2

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	G	1	?	EOT
HEX	1B	47	31	3F	04

Response to Query

As set string format with current values.

Head Select: 1 byte print head selection. This will always be 1 (31) for an Ax-Series.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will enable auto-repeat printing and set the pitch to 5000.

Sent to printer: 1B 47 31 39 39 35 30 30 30 04

Response from printer: 06

The string below should be used to disable auto-repeat printing. This is the same string that is used to disable continuous printing, see [page 4-35](#).

Sent to printer: 1B 5B 31 4E 34 30 30 30 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 47 3F 04

Response from printer: 1B 47 31 30 35 30 34 36 35 31 04

Printing Acknowledgement Flags – 'I' 49_h

This command instructs the printer to send a character from the serial port, or over the Ethernet interface of the printer after each printed label. The print acknowledgement is transmitted as the single character specified, without a command header or terminator.

Set String Format

	ESC	Command ID	Head Select	Acknowledgement Character	EOT
ASCII	ESC	I	1	Space, 1 to 4 or A to Z or a to d	EOT
HEX	1B	49	31	20, 31 to 34 or 41 to 5A or 61 to 64	04

Head Select: 1 byte print head selection. This is always 1 (31) for Ax-Series.

Acknowledgement Character: 1 Byte that specifies the printer acknowledgment character.
Valid characters: 1 to 4 (31 to 34), A to Z (41 to 5A) or a to d (61 to 64).
<space> (20) = off
Default is off

Note: If set to any of the characters between 'a' to 'd' (61h to 64h) inclusively, the print acknowledgment character will be converted to the control characters listed below.
a (61) = <FS> (1Ch i.e. file separator)
b (62) = <GS> (1Dh i.e. group separator)
c (63) = <RS> (1Eh i.e. record separator)
d (64) = <US> (1Fh i.e. unit separator)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	I	1	?	EOT
HEX	1B	49	31	3F	04

Head Select: 1 Byte print head selection. This is always 1 (31) for Ax-Series.

Response to Query

Same as set string format with current values.

Note: If set to any of the characters between 'a' to 'd' (61h to 64h) inclusively, the print acknowledgment character will be converted to the control characters listed below in the returned response.

a (61) = <FS> (1Ch i.e. file separator)

b (62) = <GS> (1Dh i.e. group separator)

c (63) = <RS> (1Eh i.e. record separator)

d (64) = <US> (1Fh i.e. unit separator)

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the printing acknowledgement flag to a space.

Sent to printer: 1B 49 31 20 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 49 3F 04

Response from printer: 1B 49 31 20 04

Flight Time Compensation – 'J' 4A_h

This command sets the time of flight (Flight Time Compensation), which is a means of keeping the printed label in the same place irrespective of changes in the print surface speed.

The delays between detecting the print go signal and having the ink drops arrive at the print surface is a combination of three different delays:

- The time the photocell/product detect sensor takes to “see” the product.
- The time the programme takes to prepare the label.
- The time it takes for the ink drop, once charged, to arrive at the print surface.

There is an initial compulsory pre-print delay which is reduced more and more as the line speed increases so that at low line speeds there is a small delay before the first drops are charged, but at high line speeds the first drops are charged immediately.

Set String Format

	ESC	Command ID	Head Select	Print Delay	EOT
ASCII	ESC	J	1	0000 to 9999	EOT
HEX	1B	4A	31	30303030 to 39393939	04

Head Select: 1 Byte print head selection. This is always 1 (31) for Ax-Series printer.

Print Delay: 4 Bytes to set the print delay in milliseconds.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	J	1	?	EOT
HEX	1B	4A	31	3F	04

Head Select: 1 Byte print head selection. This is always 1 (31) for Ax-Series.

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the delay to 2000 milliseconds.

Sent to printer: 1B 4A 31 32 30 30 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response. This example indicates the current flight delay is 2000 milliseconds.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4A 31 3F 04

Response from printer: 1B 4A 31 32 30 30 30 04

Product Detect Signal Level – 'L' 4C_h

This command selects the logic high or low level as the trigger for the Print Go signal.

Note: During first initialisation, or initialisation following the reset of the battery-backed memory, the printer monitors the product detect input and assumes that the values read correspond to their inactive states.

Set String Format

	ESC	Command ID	Head Select	Signal Level	EOT
ASCII	ESC	L	1	H or L	EOT
HEX	1B	4C	31	48 or 4C	04

Head Select: 1 Byte print head selection. This is always 1 (31) for Ax-Series printer.

Signal Level: 1 Byte to specify the product detect signal level.

H (48) = High

L (4C) = Low

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	L	1	?	EOT
HEX	1B	4C	31	3F	04

Head Select: 1 Byte print head selection. This is always 1 (31) for Ax-Series.

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the product detect signal level to low.

Sent to printer: 1B 4C 31 4C 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4C 31 3F 04

Response from printer: 1B 4C 31 4C 04

Product Detect Signal Persistence Time – 'M' 4D_h

This command sets the minimum time (number of print strokes) for which a change in the state of a product detect signal has to persist before it takes effect.

Note: As this is a number of strokes not real time care must be taken when the print signal is a fixed duration pulse and stroke pulses are from a shaft encoder, at low product speeds the print signal duration may not be long enough to initiate a print.

Set String Format

	ESC	Command ID	Which Product Detect	Minimum Persistence	EOT
ASCII	ESC	M	1 or 2	00000 to 65535	EOT
HEX	1B	4D	31 or 32	3030303030 to 3635353335	04

Which Product Detect: 1 Byte product detect selection. For an Ax-Series, 1 and 2 (31 and 32) are the same.

Minimum Persistence: 5 Byte, minimum product detect signal persistence. Range: 0000 to 65535 (3030303030 to 3635353335)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Which Product Detect	Query Command	EOT
ASCII	ESC	M	1 or 2	?	EOT
HEX	1B	4D	31 or 32	3F	04

Which Product Detect: 1 Byte product detect selection. For an Ax-Series, 1 and 2 (31 and 32) are the same.

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the product detect signal persistence to 0000.

Sent to printer: 1B 4D 31 30 30 30 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4D 31 3F 04

Response from printer: 1B 4D 31 30 30 30 30 32 04

Print Go – 'N' 4E_h

This command will initiate printing. The printer will behave in the same way as when a print-go signal is received from a product detect sensor.

Set String Format

	ESC	Command ID	Which Product Detect	EOT
ASCII	ESC	N	1 or 2	EOT
HEX	1B	4E	31 or 32	04

Which Product Detect: 1 Byte product detect selection. For an Ax-Series, 1 and 2 (31 and 32) are the same.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

Sent to printer: 1B 4E 31 04

Response from printer: 06

Get label from store and put online – 'P' 50_h

This command is used to set or query a label on-line from the store if its slot ID is known. The label is put online from the current label store selected.

Set String Format

	ESC	Command ID	Head Select	Label Slot ID	EOT
ASCII	ESC	P	1	001 to 255	EOT
HEX	1B	50	31	303031 to 323535	04

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series.

Label Slot ID: 3 Byte label buffer selection.
Range: 001 to 255 (303031 to 323535).

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	P	1	?	EOT
HEX	1B	50	31	3F	04

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series.

Response to Query

As set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will put the label assigned to slot number 009 online.

Sent to printer: 1B 50 31 30 30 39 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 50 31 3F 04

Response from printer: 1B 50 31 30 30 30 04

Head Enable – 'Q' 51_h

This command will set the print head to enable or disable printing. The query returns the status of the print head.

Set String Format

	ESC	Command ID	Head Select	Head Enable	EOT
ASCII	ESC	Q	1	Y = Enable N = Disable	EOT
HEX	1B	51	31	59 = Enable 4E = Disable	04

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series.

Head Enable 1 Byte print head enable.
Y (59) = Enable
N (4E) = Disable

Note: On a Duo print head, the command applies to both ink jets.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	Q	1	?	EOT
HEX	1B	51	31	3F	04

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series.

Response to Query

As set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will disable the print head.

Sent to printer: 1B 51 31 4E 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 51 31 3F 04

Response from printer: 1B 51 31 4E 04

Clear All Labels – 'R' 52_h

This command will take all labels off-line.

Set String Format

	ESC	Command ID	EOT
ASCII	ESC	R	EOT
HEX	1B	52	04

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

Sent to printer: 1B 52 04

Response from printer: 06

Store Label with Name as 3 digits – 'S' 53_h

This command allows labels to be sent to the label store and stored using a 3 Byte/digit label name. The command also allows the contents of a label with a 3 Byte/digit label name to be queried.

Note: If the newly saved label (e.g. 001) has the same name as the current label online (e.g. 001), on successfully saving the label, it will be reloaded online again. Any amendments to the label will take effect immediately online.

Set String Format

	ESC	Command ID	Label Name	Label Data	EOT
ASCII	ESC	S	000 to 255	<Space> to <Delete>	EOT
HEX	1B	53	303030 to 323535	20 to 7F	04

Label Name: 3 Byte/digit label buffer number.
Range: 001 to 255 (303031 to 323535).

Label Data: Label data characters.
Valid characters: <Space> to <Delete> (20 to 7F) or embedded format commands.

- Notes: (1) If the label name is in 3 Bytes/digits then the label slot name is used as the slot number, so the label is saved as the "3 digit name".smg. If the name is saved as a three character name then the label slot number can differ from the label name.*
- (2) If the location (number) is already occupied on the printer, it will be overwritten.*
- (3) The label will be stored and read from the current label store selected.*
- (4) Requesting label name 000 (303030) will return the label from the editor.*

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Label Name	Query Command	EOT
ASCII	ESC	S	000 to 255	?	EOT
HEX	1B	53	303031 to 323535	3F	04

Label Name: 3 Byte/digit label buffer number.
Range: 001 to 255 (303031 to 323535).

Response to Query

Same as set string format with current values.

Worked Examples

Transfer a Simple Label to the Printer Store

To Printer:

	ESC	Command ID	Label Name			Label Data									
ASCII	ESC	S	9	9	9	H	e	l	l	o		W	o	r	l
HEX	1B	53	39	39	39	48	65	6C	6C	6F	20	57	6F	72	6C

Label Data	EOT
d	EOT
64	04

From Printer:

ACK
06

Transfer a Complex Label to the Printer Store

We are going to create the following label and store it on the printer as a label named 123.

1-7
2-7
3-7
4-7
3216162121
161616777

To Printer:

	ESC	Command ID	Label Name			ESC	Font Height		Label Data				ESC
ASCII	ESC	S	1	2	3	ESC	u	1	1	-	7	ESC	
HEX	1B	53	31	32	33	1B	75	31	31	2D	37	1B	

Font Height		Label Data		EOT	Font Height				CR		Label Data		Font Height		Label Data		
u	4	3	2	ESC	u	2	1	6	ESC	r	1	7	ESC	u	2	1	6
75	34	33	32	1B	75	32	31	36	1B	72	31	37	1B	75	32	31	36

Note: The above command string continues on the next page.

PRINTER CONTROL COMMANDS

Font Height			Label Data					Font Height			Label Data		Font Height			Label Data	
ESC	u	1	7					ESC	u	3	2	1	ESC	u	1	7	
1B	75	31	37	20	20	20	20	1B	75	33	32	31	1B	75	31	37	

CR		Font Height			Label Data				Font Height			Label Data		Font Height		
ESC	r	ESC	u	1	2	-	7	7	ESC	u	2	1	6	ESC	u	3
1B	72	1B	75	31	32	2D	37	37	1B	75	32	31	36	1B	75	33

Label Data		CR		Label Data			Font Height			Label Data				Font Height		
2	1	ESC	r	3	-	7	ESC	u	2	1	6	1	6	ESC	u	1
32	31	1B	72	33	2D	37	1B	75	32	31	36	31	36	1B	75	31

Label Data		CR		Font Height			Label Data										EOT
7		ESC	r	ESC	u	1	4	-	7	7	7					7	EOT
37		1B	72	1B	75	31	34	2D	37	37	37	20	20	20	20	37	04

From Printer:

ACK
06

Transfer a label that embeds a serial number in a bar code and also prints the serial number as a number next to it as illustrated below. The bar code type used is 2 of 5 interleaved with no check sum.



006789

PRINTER CONTROL COMMANDS

To printer:

	ESC	Command ID	Label Name			ESC	Insert Barcode	2 of 5 Interleaved no Checksum	ESC
ASCII	ESC	S	7	8	9	ESC	q	2	ESC
HEX	1B	53	37	38	39	1B	71	32	1B

Insert Serial Number	Serial Number ID	Not Batch Linked	Numeric Field Width			First Numeric Limit	1st Numeric Limit				
j	1	N	0	6		0	0	0	0	0	0
6A	31	4E	30	36		30	30	30	30	30	30

2nd Numeric Limit						Numeric Step Size						Has Leading Zeros	Insert Serial Number
9	9	9	9	9	9	0	0	0	0	0	1	Y	j
39	39	39	39	39	39	30	30	30	30	30	31	59	6A

Serial Number ID	Not Batch Linked	Numeric Field Width		1st Numeric Limit						2nd numeric Limit							
2	N	0	6	0	0	0	0	0	0	0	9	9	9	9	9	9	9
32	4E	30	36	30	30	30	30	30	30	30	39	39	39	39	39	39	39

Numeric Step Size						Has Leading Zeros	No Suffix or Prefix	Start Value						
0	0	0	0	0	1	Y	N	0	0	0	6	7	8	9
30	30	30	30	30	31	59	4E	30	30	30	36	37	38	39

Note: The above command string continues on the next page.

Number of times each number will be repeat printed					Numeric Steps	EOT
0	0	0	0	0	N	EOT
30	30	30	30	30	4E	04

From Printer:

06
ACK

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will store a label named "001" with the data "ABC" in the printer's label store.

Sent to printer: 1B 53 30 30 31 41 42 43 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer, and the printer's response.

Notes: (1) The string sent to the printer in the example below will request data from a label named 001 from the printer's label store.

(2) The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 53 30 30 31 3F 04

Response from printer: 1B 53 30 30 39 45 46 47 43 42 04

Product Counts – 'T' 54_h

This command resets or reads the specified product counter within the printer. Counter 2 (“Prints since power on”) can only be reset if it is configured to be persistent (“Resettable counter 2”). A negative acknowledgement NAK (15) will be returned on attempting to reset or query counter 2 if it is non-persistent (“Prints since power on”).

Note: The count is of photocell transitions and not necessarily the number of codes printed. For example, on an Ax-Series printer the ink jet might be off.

Set String Format

	ESC	Command ID	Counter ID	Reset	EOT
ASCII	ESC	T	1 or 2	0	EOT
HEX	1B	54	31 or 32	30	04

Counter ID: 1 Byte to select the counter that will be reset.
 1 (31) = Counter 1
 2 (32) = Counter 2

Reset: 1 Byte counter reset number 0 (30).

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Counter ID	Query Command	EOT
ASCII	ESC	T	1 or 2	?	EOT
HEX	1B	54	31 or 32	3F	04

Counter ID: 1 Byte counter identity.
 1 (31) = Counter 1
 2 (32) = Counter 2

Response to Query

	ESC	Command ID	Counter ID	Query Response	EOT
ASCII	ESC	T	1 or 2	0000000000 to 9999999999	EOT
HEX	1B	54	31 or 32	303030303030303030 to 393939393939393939	04

Counter ID: 1 Byte counter identity.
 1 (31) = Counter 1
 2 (32) = Counter 2

Query Response: 10 Byte counter value with padded leading zeros.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will reset product counter one.

Sent to printer: 1B 54 31 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 54 31 3F 04

Response from printer: 1B 54 31 30 30 30 30 30 38 32 34 34 34 04

Stroke Rate – 'V' 56_h

This command will return the current stroke rate.

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	V	?	EOT
HEX	1B	56	3F	04

Response to Query

	ESC	Command ID	Stroke Rate	EOT
ASCII	ESC	V	00001 to 80000	EOT
HEX	1B	56	3030303031 to 3830303030	04

Stroke Rate: 5 Byte stroke rate value.
Range: 00001 to 80000 (3030303031 to 3830303030)

For A-Series plus and i-Tech, this is the internal stroke rate setting.

In the Ax-Series, this returns the inverse value in the user interface, e.g. 8000 will return 00125.

A response of ?????? means that the stroke rate exceeds the measurement capability of the printer, i.e. very slow stroke rate.

Some returns may be more than 5 Byte long.

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 56 3F 04

Response from printer: 1B 56 31 31 36 32 38 04

Read Modification Level – 'W' 57_h

On Macrojet, Casocode and Codebox printers, this command is used by the pocket terminal to identify the functions allowed on a particular machine's software. This command currently serves no purpose on other printer types. This command has only been implemented to maintain compatibility with older controllers. If you are writing commands for a new controller, there is no need to implement this command.

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	W	?	EOT
HEX	1B	57	3F	04

Response to Query

Note: The modification status will always return 2 for A-Series or Ax-Series products.

	ESC	Command ID	Modification Status	EOT
ASCII	ESC	W	2	EOT
HEX	1B	57	32	04

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 57 3F 04

Response from printer: 1B 57 32 04

External Label Select – '@' 40_h

This command enables or disables external label selection. It will take the labels from the printer's internal label store and put them online by sending them to the Stroke Generator Board (SGB). Once on the SGB, use the parallel binary select lines to allow the selection of one of the labels to be printed.

Notes: (1) For Ax-Series the valid label select lines are 001-255.

(2) Label selection does not start at 000 as this is the currently printing label.

(3) Changing a label can take 250mS to 750mS depending on the type of data in the label.

(4) This facility is only available if MOD_STATE > 0.

Set String Format

	ESC	Command ID	Enable or Disable	EOT
ASCII	ESC	@	Y or N	EOT
HEX	1B	40	59 or 4E	04

Enable or Disable: Single character to enable or disable external label selection.
 Y (59) = Enable
 N (4E) = Disable.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	@	?	EOT
HEX	1B	40	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

Note: The string sent to the printer in the example below will enable external label selection.

Sent to printer: 1B 40 59 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 40 3F 04

Response from printer: 1B 40 4E 04

Continuous Printing – '[' 5B_h

This command is similar to Auto Repeat, but printing will continue without needing to set a “Number to Print” field. More importantly, any clock or numbering data will be updated before each print. The pitch is from the front of one label to the front of the next label. The accuracy of the repeat pitch will be subject to many variables, especially the inclusion of clock and numbering, so accuracy cannot be guaranteed. Values of 0 and 1 are interpreted as 2.

Set String Format

	ESC	Command ID	Head Select	On or Off	Label Pitch	EOT
ASCII	ESC	[1	Y or N	00000 to 99999	EOT
HEX	1B	5B	31	59 or 4E	3030303030 to 3939393939	04

Head Select: 1 Byte print head selection. This is always 1 (31) for an Ax-Series printer.

On or Off: 1 character to enable or disable.
 Y (59) = Enable
 N (4E) = Disable

Label Pitch: 5 Byte inter label pitch
 Range: 00000 to 99999 (3030303030 to 3939393939).

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	[?	EOT
HEX	1B	5B	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will enable continuous printing and set the label pitch to 40,000.

Sent to printer: 1B 5B 31 59 34 30 30 30 30 04

Response from printer: 06

The string sent to the printer in the example below will disable continuous printing.

Sent to printer: 1B 5B 31 4E 34 30 30 30 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 5B 3F 04

Response from printer: 1B 5B 31 4E 34 30 30 30 30 04

Switch Label Monitor Updating On/Off – '~E' 7E_h 45_h

This command will switch on/off the label preview being shown on the user interface. This feature may be useful when printing at high speed to ensure that the printer's resources are optimised for printing. When printing at high speeds the refresh rate of the screen will be too slow to view every preview anyway.

Set String Format

	ESC	Command ID	State of Label Monitor	EOT
ASCII	ESC	~E	1 or 0	EOT
HEX	1B	7E45	31 or 30	04

State of Label Monitor: 1 Byte to enable or disable label monitoring.
 1 (31) = Enable
 0 (30) = Disable

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	~E	?	EOT
HEX	1B	7E45	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will enable label monitor updating.

Sent to printer: 1B 7E 45 31 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 7E 45 3F 04

Response from printer: 1B 7E 45 31 04

Number of items in the FIFO Data Buffer – '~G' 7E_h 47_h

Note: This command has been superseded by command 7E_h 50_h, see [page 4-40](#).

The query will return the number of items in the FIFO Data Buffer for the specified transport method. The command can return a maximum number of 32.

Query String Format

	ESC	Command	Transport Method	Query Command	EOT
ASCII	ESC	~G	0 or 1	?	EOT
HEX	1B	7E47	30 or 31	3F	04

Transport Method: 1 byte that specifies the transport method.
 0 (30) = Ethernet
 1 (31) = RS232

Response to Query

	ESC	Command	Number of Label Items in Buffer	EOT
ASCII	ESC	~G	NUL to US	EOT
HEX	1B	7E47	00 to 1F	04

Number of label items in buffer: 1 bit to specify the number of items in the FIFO buffer.
 Range: 00 to FF (NUL NUL to ý ý)

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Notes: (1) The response below indicates there are 5 items in the FIFO buffer.

(2) The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 7E 47 30 3F 04

Response from printer: 1B 7E 47 05 04

Number of items in the FIFO Data Buffer – '~P' 7E_h 50_h

The query will return the number of items in the FIFO Data Buffer for the specified transport method. The command can return any number up to 65535, but is currently limited to maximum FIFO queue size in the printers software (4096).

Query String Format

	ESC	Command ID	Transport Method	Query Command	EOT
ASCII	ESC	~P	0 or 1	?	EOT
HEX	1B	7E50	30 or 31	3F	04

Transport Method: 1 byte that specifies the transport method.
 0 (30) = Ethernet
 1 (31) = RS232

Response to Query

	ESC	Command ID	Number of label items in buffer	EOT
ASCII	ESC	~E	NUL NUL to ÿ ÿ	EOT
HEX	1B	7E50	0000 to FFFF	04

Number of label items in buffer: 2 bytes that specify the number of items in the FIFO buffer.
 Range: 0000 to FFFF (NUL NUL to ÿÿÿÿ)

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Notes: (1) The response below indicates there are 5 items in the FIFO buffer.

(2) The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 7E 50 30 3F 04

Response from printer: 1B 7E 50 00 05 04

Connection Count – '~H' 7E_h 48_h

Returns the number of Ethernet connections the printer has open. This number will include the local host connections if there are any.

Query String Format

	ESC	Command ID	Query Command (1 Byte)	EOT
ASCII	ESC	~H	?	EOT
HEX	1B	7E48	3F	04

Response to Query

	ESC	Command ID	Number of Connections (2 Bytes)	EOT
ASCII	ESC	~H	01 to 99	EOT
HEX	1B	7E48	3031 to 3939	04

Number of Connections: 2 digit that specify the number of open Ethernet connections.
 Range: 01 to 99 (3031 to 3939)

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 7E 48 3F 04

Response from printer: 1B 7E 48 31 33 04

Reset Ethernet Connections – '~I' 7E_h 49_h

This command will reset all open Ethernet connections to the printer. This includes Local Host connections.

Set String Format

	ESC	Command ID	EOT
ASCII	ESC	~I	EOT
HEX	1B	7E49	04

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

Sent to printer: 1B 7E 49 04

Response from printer: 06

Reset FIFO Data Buffer – '~J' 7E_h 4A_h

This command will reset the FIFO buffer. This means that all data already in the buffer will be deleted.

Set String Format

	ESC	Command ID	Transport Stream	EOT
ASCII	ESC	~J	0 or 1	EOT
HEX	1B	7E4A	30 or 31	04

Transport Stream: One byte to specify the transport stream.
 0 (30) = RS232
 1 (31) = Ethernet

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negatives

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

Sent to printer: 1B 7E 4A 31 04

Response from printer: 06

THIS PAGE INTENTIONALLY LEFT BLANK

PART 5 : PRINTER STATUS COMMANDS

CONTENTS

	Page
PRINTER STATUS COMMANDS	5-3
Status Reporting Mode – '0' 30h	5-3
Set String Format	5-3
Response to Set	5-3
Query String Format	5-3
Response to Query	5-3
Set and Response String Examples	5-4
Query and Response String Examples	5-4
Status Request – '1' 31h	5-5
Query String Format	5-5
Response to Query	5-5
Status Table	5-6
Query and Response String Examples	5-8
Read Liquid Levels – 'y' 79h	5-9
Query String Format	5-9
Response to Query	5-9
Query and Response String Examples.....	5-10

PRINTER STATUS COMMANDS

THIS PAGE INTENTIONALLY LEFT BLANK

PRINTER STATUS COMMANDS

Status Reporting Mode – '0' 30_h

This command sets the mode for reporting printer status changes. This command switches the feature on or off, while command 31 allows you inspect them.

Set String Format

	ESC	Command ID	Unsolicited Reporting	Mode Control	EOT
ASCII	ESC	0	Y or N	0 to 7	04
HEX	1B	30	59 or 4E	30 to 37	EOT

Unsolicited Reporting: 1 Byte to enable or disable unsolicited reporting.
 Y (59) = Enable
 N (4E) = Disable

Mode Control: 1 Byte mode control.
 0 (30) = No Error Reporting
 1 (31) = Serial Interface Status
 2 (32) = Fault Monitor Status
 3 (33) = Serial Int. and Fault Monitor Status
 4 (34) = Ink Monitor Faults
 5 (35) = Serial Int. and Ink Monitor Status
 6 (36) = Fault and Ink Monitor Status
 7 (37) = Serial Int. Fault and Ink Monitor Status

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	0	?	04
HEX	1B	30	3F	EOT

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will disable status reporting.

Sent to printer: 1B 30 4E 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 30 3F 04

Response from printer: 1B 30 4E 30 04

Status Request – '1' 31_h

This command will cause the printer to send its current or historical status, whether unsolicited reporting is enabled or not. Unsolicited status reports will be generated (without asking) if reporting is enabled and a change of status occurs. The printer buffers the last 16 status change reports in a FiFo queue until the request for historical status is received. The printer will transmit the oldest report that it has buffered and deletes it. If no reports have been buffered by the printer since the last status request was serviced, a single current status label will be returned to the host system. This is also the case when the current status is requested.


Query String Format

	ESC	Command ID	Query Type	Query Command	EOT
ASCII	ESC	1	H or C	?	04
HEX	1B	31	48 or 43	3F	EOT

Query Type: 1 character that identifies the status query type.
 H (48) = Historical Status
 C (43) = Current Status

Response to Query

	ESC	Command ID	Query Type	Current Status	Ink Jet
ASCII	ESC	1	H or C	000 to 999	0 to 3
HEX	1B	31	48 or 43	303030 to 393939	30 to 33



Status Change Time	EOT
0000 to 2359	04
30303030 to 32333539	EOT

Query Type: 1 character that identifies the status query type.
 H (48) = Historical Status
 C (43) = Current Status

Current Status: 3 Bytes that identify the printer status. See “Status Table” on page 5-6.
 Range: 000 to 999 (303030 to 393939)

PRINTER STATUS COMMANDS

Ink Jet: One Byte to identify the ink jet.
 0 (30) = not applicable
 1 (31) = first ink jet
 2 (32) = second ink jet on a duo print head
 3 (33) = both ink jets on a duo print head

Status Change Time: Four Byte status change time in the format HHMM.
 Range: 0000 to 2359 (30303030 to 32333539)

Status Table

Status Number	Status Description	0xx Status changed from abnormal to normal	1xx Status changed to abnormal (Warning)	2xx Status changed to abnormal (Printing inhibited)	9xx Undefined status codes.
x00	Printer Ready	Normal	Fault		
x04	Charge circuit	Recovered	Failed		
x05	Solvent level	OK		Low	
x06	Solvent empty			Empty	
x07	Ink Level	OK	Low		
x08	24 Hours to Sump Expires	Yes			
x09	2 Hours to Sump Expires	Yes			
x10	Head Purge	Deactivated	Activated		
x11	Stroke Rate	OK	Too Fast		
x15	Second character set absent		Yes		
x16	Incompatible second character set		Yes		
x17	Missed output stroke(s) due to high stroke rate		Yes		

PRINTER STATUS COMMANDS

Status Number	Status Description	0xx Status changed from abnormal to normal	1xx Status changed to abnormal (Warning)	2xx Status changed to abnormal (Printing inhibited)	9xx Undefined status codes.
x18	Ink bag	OK	Empty		
x20	Ink monitor	Normal			
x21	Viscosity out of normal working range			Yes	
x22	Viscometer timed out			Yes	
x23	Wrong sump installed			Yes	
x24	Sump empty			Yes	
x25	Sump expired - supersedes sump 2 hours warning			Yes	
x26	EHT supply	Recovered		Failed	
x27	Ink on charge electrode	OK		Detected	
x28	Phase lock	Recovered		Lost	
x29	Charge circuit	Recovered		Tripped	
x30	Modulation	Recovered		Failed	
x31	Jet alignment	OK		misaligned	
x32	Temperature out of normal working range			Yes	
x33	Pressure out of normal working range			Yes	

PRINTER STATUS COMMANDS

Status Number	Status Description	0xx Status changed from abnormal to normal	1xx Status changed to abnormal (Warning)	2xx Status changed to abnormal (Printing inhibited)	9xx Undefined status codes.
x99	Undefined Alert				Yes

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 31 43 3F 04

Response from printer: 1B 31 43 39 39 39 31 31 33 31 31 04

Read Liquid Levels – 'y' 79_h

This command will return the printer's current ink and make-up levels. To find out if the levels are Low, OK or High you will need to check the LEDs on the front panel on the printer's cabinet or look at the printer's user interface. An engineer certified by Domino can use a service key to find out the actual value ranges that have been set for each level if required.

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	y	?	04
HEX	1B	79	3F	EOT

Response to Query

	ESC	Command ID	Ink Level	Make-up Level	EOT
ASCII	ESC	y	000 to 008	000 to 008	04
HEX	1B	79	303030 to 303038	303030 to 303038	EOT

Ink Level: Three Bytes that identify the ink level. If the value 021 (303231) is reported, the ink level sensor is unplugged.

000 (303030) = 0% to 12%
 001 (303031) = 13% to 24%
 002 (303032) = 25% to 37%
 003 (303033) = 38% to 49%
 004 (303034) = 50% to 62%
 005 (303035) = 63% to 74%
 006 (303036) = 75% to 87%
 007 (303037) = 88% to 99%
 008 (303038) = 100%

Make-up Level Three Bytes that identify the ink level. If the value 021 (303231) is reported, the make-up level sensor is unplugged.

000 (303030) = 0% to 12%
 001 (303031) = 13% to 24%
 002 (303032) = 25% to 37%
 003 (303033) = 38% to 49%
 004 (303034) = 50% to 62%
 005 (303035) = 63% to 74%
 006 (303036) = 75% to 87%
 007 (303037) = 88% to 99%
 008 (303038) = 100%

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 79 3F 04

Response from printer: 1B 79 30 30 30 30 30 04

PART 6 : GLOBAL PRINTER FORMAT COMMANDS

CONTENTS

	Page
PRINTER GLOBAL FORMAT COMMANDS	6-3
Global Label Reverse – 'a' 61h	6-3
Set String Format	6-3
Response to Set	6-3
Query String Format	6-3
Response to Query	6-3
Set and Response String Examples	6-4
Query and Response String Examples	6-4
Label Bold – 'b' 62h	6-5
Set String Format	6-5
Response to Set	6-5
Query String Format	6-5
Response to Query	6-5
Set and Response String Examples	6-5
Query and Response String Examples	6-6
Label Double Space – 'c' 63h	6-7
Set String Format	6-7
Response to Set	6-7
Query String Format	6-7
Response to Query	6-7
Set and Response String Examples	6-7
Query and Response String Examples	6-8
Barcode Thickness Ratio – 'f' 66h	6-9
Set String Format	6-9
Response to Set	6-10
Query String Format	6-10
Response to Query	6-10
Set and Response String Examples	6-10
Query and Response String Examples	6-10
Global Print Format – 'g' 67h	6-11
Set String Format	6-11
Response to Set	6-11
Query String Format	6-12
Response to Query	6-12
Set and Response String Examples	6-12
Query and Response String Examples	6-12
Label Invert – '~M' 7Eh 4Dh	6-13
Set String Format	6-13
Response to Set	6-13
Query String Format	6-13
Response to Query	6-13
Set and Response String Examples	6-13
Query and Response String Examples	6-14

THIS PAGE INTENTIONALLY LEFT BLANK

PRINTER GLOBAL FORMAT COMMANDS

Global commands act on every label when they are switched on.

Furthermore, global commands act in addition to embedded commands. For example, if the label is set with an embedded command to print bold and the global command is also set to print bold, a double bold label will be printed.

Global Label Reverse – 'a' 61_h

This command will cause all label fields in all labels to be printed in reverse until the command is switched off. For duo print heads, this setting applies to both ink jets.

Set String Format

	ESC	Command ID	Head Select	Mode Control	EOT
ASCII	ESC	a	1	Y or N	04
HEX	1B	61	31	59 or 4E	EOT

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series printer.

Mode Control: 1 character to enable or disable the global label reverse command.
Y (59) = Enable
N (4E) = Disable

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	a	?	04
HEX	1B	61	3F	EOT

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will disable label reverse.

Sent to printer: 1B 61 31 4E 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 61 31 3F 04

Response from printer: 1B 61 31 4E 04

Label Bold – 'b' 62_h

This command will print all labels in bold characters until it is switched off.

Set String Format

	ESC	Command ID	Head Select	Mode Control	EOT
ASCII	ESC	b	1	Y or N	04
HEX	1B	62	31	59 or 4E	EOT

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series printer.

Mode Control: 1 character to enable or disable the global label bold command.
Y (59) = Enable
N (4E) = Disable

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	b	?	04
HEX	1B	62	3F	EOT

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will disable label bold characters.

Sent to printer: 1B 62 31 4E 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 62 31 3F 04

Response from printer: 1B 62 31 4E 04

Label Double Space – 'c' 63_h

This command will cause all labels to be printed with double spacing until it is switched off.

Note: Ax-Series does not currently support this feature. However, it will return an ACK for a valid SET request. Queries will always return N (4E).

Set String Format

	ESC	Command ID	Head Select	Mode Control	EOT
ASCII	ESC	c	1	Y or N	04
HEX	1B	63	31	59 or 4E	EOT

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series printer.

Mode Control: 1 character to enable or disable the global label double space command.
Y (59) = Enable
N (4E) = Disable

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	c	?	04
HEX	1B	63	3F	EOT

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will disable label double space.

Sent to printer: 1B 63 31 4E 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 63 31 3F 04

Response from printer: 1B 63 31 4E 04

Barcode Thickness Ratio – 'f' 66_h

This command adjusts the ratio of bar and space element thickness employed in barcode printing. It allows the user to optimise the readability of printed barcodes.

Set String Format

	ESC	Command ID	Head Select	Barcode Type	Module Width
ASCII	ESC	f	1	1 to 4	1 to 10
HEX	1B	66	31	31 to 34	31 to 0A

Space to Module Width Ratio	Wide to Module Width Ratio	Not Used	EOT
1 or 2	0 to 8	0	04
31 or 32	30 to 38	30	EOT

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series printer.

Barcode Type: 1 Byte to select the barcode type.
 1 (31) = Code 39
 2 (32) = D2 of 5 Interleaved
 3 (33) = USPS
 4 (34) = EAN / UPC

Module Width: 1 Byte module width.
 Range: 1 to 10 (31 to 0A)

Space to Module Width Ratio: One Byte space to module width ratio.
 1 (31) = Ratio 1:1
 2 (32) = Ratio 2:1

Wide to Module Width Ratio: One Byte wide to module width ratio.
 The ratio will be the wide ratio multiplied by the module width and rounded up to the nearest integer.
 Range: 0 to 8 (30 to 38) meaning 2.0:1 to 2.8:1

Not Used: One Byte always set to 0 (30).

- Notes: (1) Code 39 - Element widths: Default module width is 1, space to module width ratio is 1:1 and wide to module width ratio is 2:1
- (2) Interleaved 2 of 5 - Element widths: Default module width is 1, space to module width ratio is 1:1 and wide to module width ratio is 2:1.
- (3) EAN/UPC - Element widths: The widths can be increased or reduced only by changing the module width.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Barcode Type	Query Command	EOT
ASCII	ESC	f	1	1 to 4	?	04
HEX	1B	66	31	31 to 34	3F	EOT

Response to Query

As set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the barcode type to Code 39, module width to 1, space to module width ration to 2:1 and wide to module width ratio to 2.2:1.

Sent to printer: 1B 66 31 31 31 32 32 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer, and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 66 31 31 3F 04

Response from printer: 1B 66 31 31 31 32 32 34 04

Global Print Format – 'g' 67_h

This command collectively sets the global attributes for printed label orientation.

Note: In Ax-Series, "Global Double Space Label" is currently not supported. Queries will always return N (4E).

Set String Format

	ESC	Command ID	Head Select	Reverse Label	Bold Label
ASCII	ESC	g	1	Y or N	Y or N
HEX	1B	67	31	59 or 4E	59 or 4E

Double Space Label	Invert Label	Not Used	EOT
Y or N	Y or N	N	04
59 or 4E	59 or 4E	4E	EOT

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series printer.

Reverse Label: 1 Byte to enable or disable the global reverse label command.
Y (59) = Enable
N (4E) = Disable

Bold Label: 1 Byte to enable or disable the global bold label command.
Y (59) = Enable
N (4E) = Disable

Double Space Label: 1 Byte to enable or disable the global double space label command.
Y (59) = Enable
N (4E) = Disable

Invert Label: 1 Byte to enable or disable the global invert label command.
Y (59) = Enable
N (4E) = Disable

Not Used: Always set to N (4E).

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	g	1	?	04
HEX	1B	67	31	3F	EOT

Response to Query

As set format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will disable all of the label orientation settings.

Sent to printer: 1B 67 31 4E 4E 4E 4E 4E 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 67 31 3F 04

Response from printer: 1B 67 31 4E 4E 4E 59 4E 04

Label Invert – '~M' 7E_h 4D_h

This command will print all labels inverted until it is switched off. For Duo printers, this setting is common for both ink jets.

Set String Format

	ESC	Command ID	Head Select	Mode Control	EOT
ASCII	ESC	~M	1	Y or N	04
HEX	1B	7E4D	31	59 or 4E	EOT

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series printer.

Mode Control: 1 character to enable or disable the global label invert command.
Y (59) = Enable
N (4E) = Disable

Response to Set

ACK (06) = Positive

or

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	~M	1	?	04
HEX	1B	7E4D	31	3F	EOT

Response to Query

As set format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will enable label invert.

Sent to printer: 1B 7E 4D 31 59 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of the query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 7E 4D 31 3F 04

Response from printer: 1B 7E 4D 31 59 04

PART 7 : LABEL FORMATTING COMMANDS

CONTENTS

	Page
LABEL FORMATTING COMMANDS	7-3
Insert Label Script – '+' 2Bh	7-3
Set String Format	7-3
Response to Set	7-3
Set and Response String Examples	7-3
Insert Padding Spaces – '<' 3Ch	7-4
Set String Format	7-4
Response to Set	7-4
Set and Response String Examples	7-4
Character Reverse – 'd' 64h	7-5
Set String Format	7-5
Response to Set	7-5
Set and Response String Examples	7-5
Character Invert – 'e' 65h	7-6
Set String Format	7-6
Response to Set	7-6
Set and Response String Examples	7-6
Change Unicode Page – 'h' 68h	7-7
Set String Format	7-7
Response to Set	7-7
Set and Response String Examples	7-7
Select Character – 'i' 69h	7-8
Set String Format	7-8
Response to Set	7-8
Set and Response String Examples	7-8
Insert Serial Number – 'j' 6Ah	7-9
Response to Set	7-12
Set and Response String Examples	7-12
Start Bold Characters and Logos – 'k' 6Bh	7-13
Set String Format	7-13
Response to Set	7-13
Set and Response String Examples	7-13
Insert Logo – 'm' 6Dh	7-14
Set String Format	7-14
Response to Set	7-14
Set and Response String Examples	7-14
Insert Date/Time – 'n' 6Eh	7-15
Set String Format	7-15
Response to Set	7-16
Set and Response String Examples	7-16
Offset Clock – 'o' 6Fh	7-17
Set String Format	7-17
Response to Set	7-17
Set and Response String Examples	7-18
Insert Shift Code (Time Conditional Print String) – 'p' 70h	7-19
Set String Format	7-19

LABEL FORMATTING COMMANDS

Response to Set	7-20
Set and Response String Examples	7-20
Insert Barcode – 'q' 71h	7-21
Set String Format	7-21
Barcode Type	7-21
Barcode Characteristics	7-22
Set and Response String Examples	7-23
Line Separator – 'r' 72h	7-24
Set String Format	7-24
Set and Response String Examples	7-24
Set Character Height – 'u' 75h	7-25
Set String Format	7-25
Set and Response String Examples	7-25
Stop Bold Characters – 'v' 76h	7-26
Set String Format	7-26
Response to Set	7-26
Set and Response String Examples	7-26
Insert Language Date/Time – 'w' 77h	7-27
Set String Format	7-27
Response to Set	7-28
Set and Response String Examples	7-29
Insert Bitmap – 'x' 78h	7-30
Set String Format	7-30
Response to Set	7-30
Set and Response String Examples	7-30
2D Codes – 'z' 7Ah	7-31
Set String Format	7-31
Example – Data Matrix	7-34
Set and Response String Examples	7-35
Example – QR Code	7-36
Set and Response String Examples	7-36
Insert Updatable Text Field – ' ' 7Ch	7-37
Set String Format	7-37
Example 1	7-38
Example 2	7-39
Set and Response String Examples	7-39
Insert Language Date/Time – '}' 7Dh	7-40
Set String Format	7-40
Response to Set	7-41
Set and Response String Examples	7-42
Insert a Thin Space of One Stroke – '~N' 7Eh 4Eh	7-43
Set String Format	7-43
Response to Set	7-43
Set and Response String Examples	7-43

LABEL FORMATTING COMMANDS

These commands are embedded within the text of individual labels. They have effect over parts of the printed label and are additional to any global format commands that may be active at the time of printing. Label formatting commands affect the specified label only.

Some of the commands in this group have no “End of Text” (04h) character and normally create no response from the printer. However, any unrecognised, out of range or invalid value entered, or an excessive label length will generate a negative acknowledgement when the next “End of Text” (04h) character is encountered.

Insert Label Script – '+' 2B_h

This command is used to embed a custom script within a label. If the script doesn't exist or the maximum number of scripts per label has been reached then a NAK (15) will be returned at the next EOT (04).

Set String Format

	ESC	Command ID	Script Name
ASCII	ESC	+	1..nn Byte
HEX	1B	2B	31..nn Byte

Script Name: The file name of the script including the file extension. The extension is used to show where the name ends.

- For A-Series Plus printers, the script extension is .csf
- For Ax-Series printers, the script extension is .lua
- If the extension is omitted, a NAK will be returned at the next EOT (04h).

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will insert a script called “myscript.lua” into a label named “001”.

Sent to printer: 1B 53 30 30 31 1B 2B 6D 79 73 63 72 69 70 74 2E 6C 75 61 04

Response from printer: 06

Insert Padding Spaces – '<' 3C_h

This command adds a specified number of padding spaces to a label. This allows the label to be printed in the correct position on the print surface.

This command is a shorthand method of adding spaces. Instead of adding 9 bytes in the format 2020202020202020, add 4 bytes ESC/</9/EOT (1B/3C/39/04). This adds less bytes of data allowing the printer to receive the label quicker.

Set String Format

	ESC	Command ID	Number of Spaces
ASCII	ESC	<	1 to 9
HEX	1B	3C	31 to 39

Number of Spaces: 1 Byte, number of label padding spaces.
Range: 1 to 9 (31 to 39)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "011" and save it to the printer's label store. The label will contain two text elements with the data "A" and "B". There will be nine padding spaces between the two text elements.

Sent to printer: 1B 53 30 31 31 41 1B 3C 39 42 04

Response from printer: 06

Character Reverse – 'd' 64_h

This command will cause characters at a specific point in a label to be printed in reverse, or forward if global label reverse is active until the command is switched off.

Set String Format

	ESC	Command ID	Head Select	Mode Control
ASCII	ESC	d	1	Y or N
HEX	1B	64	31	59 or 4E

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series printer.

Mode Control: 1 character to enable or disable the character reverse command.
 Y (59) = Enable
 N (4E) = Disable

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "012" and save it to the printer's label store. Two text elements will be inserted in the label. The first text element contains the data "A" and will be printed forwards. The second text element contains the data "B" and will be printed in reverse.

Sent to printer: 1B 53 30 31 32 41 1B 64 31 59 42 04

Response from printer: 06

Character Invert – 'e' 65_h

This command will cause characters to be printed in upside down until the command is switched off.

Set String Format

	ESC	Command ID	Head Select	Mode Control
ASCII	ESC	e	1	Y or N
HEX	1B	65	31	59 or 4E

Head Select: 1 Byte print head selection. This will always be 1 (31) for an Ax-Series printer.

Mode Control: 1 character to enable or disable the character invert command.
 Y (59) = Enable
 N (4E) = Disable

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "013" and save it to the printer's label store. Two text elements will be inserted in the label. The first text element contains the data "A" and will not be inverted. The second text element also contains the data "A" and will be inverted.

Sent to printer: 1B 53 30 31 33 41 1B 65 31 59 41 04

Response from printer: 06

Change Unicode Page – 'h' 68_h

By default, characters are from Unicode page number 00. The Unicode page number can be altered with the following command.

Set String Format

	ESC	Command ID	Page Number
ASCII	ESC	h	00 to FF
HEX	1B	68	3030 to 4646

Page Number: Two Bytes to specify the unicode page number.
Valid characters: 00 to FF (3030 to 5A39)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53 and 69. This will create a label named "014" and save it to the printer's label store. The label will contain two text elements, the first text element contains the data "A". The second text element contains the unicode character "32" from unicode page number 4E.

Sent to printer: 1B 53 30 31 34 41 1B 68 34 45 1B 69 33 32 04

Response from printer: 06

Select Character – 'i' 69_h

This command selects a specific character from the current Unicode page. The Unicode page can be set by using command 68, see [page 7-7](#).

Set String Format

	ESC	Command ID	Character Number
ASCII	ESC	i	00 to FF
HEX	1B	69	3030 to 4646

Page Number: Two Bytes to identify the character number.
Valid characters: 00 to FF (3030 to 4646)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The string below will select Unicode character 32 form the currently selected page.

Sent to printer: 1B 4F 51 30 30 31 1b 75 32 34 41 1B 68 34 45 1B 69 33 32 1B 69
33 33 04

Response from printer: 06

Insert Serial Number – 'j' 6A_h

This command adds a serial number to the label starting at the current line and column position, and with the current character attributes. The number of serial numbers, independent or batch linked, depends on the printer model.

Set Format:

	ESC	Command ID	Serial Number ID	Batch Linked	Numeric Field Width
ASCII	ESC	j	1 or 2	Y or N	00 to 16
HEX	1B	6A	31 or 32	59 or 4E	3030 to 3136

First Numeric Limit	Second Numeric Limit	Numeric Step Size	Print Leading Zeros	Prefix/Suffix Select
0..0 to 9..9	0..0 to 9..9	0..1 to 9..9	Y or N	P, S or N
30..30 to 39..39	3030..3030 to 3939..3939	30..31 to 39..39	59 or 4E	50, 53 or 4E

Number of Alpha Prefix/Suffix Characters	Prefix/Suffix Characters 1st Limit	Prefix/Suffix Characters 2nd Limit	Size of Numeric + Alpha Field Width	Number of Times to Repeat Each Number
0, 1 or 2	AA to ZZ	AA to ZZ	AA0..0AA to ZZ9..9ZZ	00000 to 50000
30, 31 or 32	4141 to 5A5A	4141 to 5A5A	414130..304141 to 5A5A39..395A5A	3030303030 to 3530303030

Increment Alpha or Numeric
A or N
41 or 4E

LABEL FORMATTING COMMANDS

Serial Number ID:	One Byte to select the serial number identity. 1 (31) = One 2 (32) = Two
Batch Linked:	One character batch link flag. Y (59) = Enable (Y is only valid when Serial Number ID is 2) N (4E) = Disable
Numeric Field Width:	Two Byte numeric field width. A value of 00 (3030) specifies an alpha only serial number. Range: 00 to 16 (3030 to 3136)
First Numeric Limit:	Number of Bytes depends on "Numeric Field Width" value. Range: 0..0 to 9..9 (30..30 to 39..39)
Second Numeric Limit:	Number of Bytes depends on "Numeric Field Width" value. Range: 0..0 to 9..9 (30..30 to 39..39)
Numeric Step Size:	Number of Bytes depends on "Numeric Field Width" value. Range: 0..0 to 9..9 (30..30 to 39..39)
Print Leading Zeros:	One character to enable or disable the printing of serial number leading zeros. If printing of leading zeros is disabled, spaces will be printed in place of zeros. Y (59) = Enable N (4E) = Disable
Prefix/Suffix Select:	One character to select prefix, suffix or none. P (50) = Prefix S (53) = Suffix N (4E) = None
Number of Alpha Prefix/Suffix Characters:	One number to select the number of prefix or suffix characters. A value of 0 (30) specifies a numeric only serial number. 0 (30) = Zero 1 (31) = One 2 (32) = Two
Prefix/Suffix Characters 1st Limit:	If "Number of Alpha Prefix/Suffix Characters" = zero, leave out. Range: AA to ZZ (4141 to 5A5A)
Prefix/Suffix Characters 2nd Limit:	If "Number of Alpha Prefix/Suffix Characters" = zero, leave out. Range: AA to ZZ (4141 to 5A5A)
Size of Numeric + Alpha Field Width	Start Value. Range: AA0..0AA to ZZ9..9ZZ (414130..304141 to 5A5A39..395A5A)
Number of Times to Repeat Each Number:	Five Byte repeat printing count for each value. Range: 00000 to 50000 (3030303030 to 3530303030)
Increment Alpha or Numeric:	One character, step order selection. A (41) = Alpha N (4E) = Numeric

LABEL FORMATTING COMMANDS

- Notes: (1) For two batch linked serial numbers, number 2 will be changed by the rolling over of number 1.
- (2) The batch linked field is always ignored for serial number 1. It is also ignored if serial number 2 is the only one entered.
- (3) A value of 00 in "Numeric Field Width" specifies an alpha only serial number. On Ax-Series printers, you are required to have at least a numeric field in the serial number (as only "Number of alpha prefix/suffix chars" is allowed to be 0 and its optional corresponding fields "Prefix/suffix characters 1st limit" and "Prefix/suffix characters 2nd limit" omitted when this is so) or a NAK will be returned.
- (4) A value of 0 in "Number of alpha prefix/suffix chars" specifies a numeric only serial number.
- (5) If "Numeric Field Width" and "Number of alpha prefix/suffix chars" are zero, the label will get a NAK.
- (6) If leading zeros are suppressed, then spaces will be printed in place of any leading zeros.
- (7) For a serial number embedded in a barcode, leading zeros will always be printed and suppression will be ignored.
- (8) If the first limit value is less than the second limit value, then an incrementing number will be generated: if it is greater, a decrementing number will be generated. When both limits are equal, a fixed number will be generated.
- (9) When using an Alpha increment, the Alpha prefix/suffix is incremented first. However, when using Numeric, the numeric part will increment first. Every label can have its own serial number associated with it. Please note that Ax-Series printers do not support this feature. On Ax-Series printers, if a serial number is alphanumeric, both the numeric and alpha will increase/decrease in the same direction. The increment/decrement amount is based on the value in field "Numeric step size".
- (10) Serial numbering information is remembered for label 'n' when the printer switches from printing label 'n' to printing any of the other defined labels. In this way, serial numbering of a product by label 'n' can be resumed at a later stage from where it left off. The contents of the serial numbering definition together with the next serial number value to be printed for the label (in the "Start Value" field) will be read back whenever the stored label is used again. To enable this feature on Ax-Series printers, you will be required to tick the "Counter persistence on" checkbox on the Codenet protocol configuration screen in the printer's QuickStep user interface.
- (11) For A100 single jet head printers there is a limit of 1 serial number per label.
- (12) For all other printers, there is a limit of 2 serial numbers per label. For a Duo printer this limit applies across both regions.
- (13) On Ax-Series printers, the "Start value" is used to determine the format of the serial number. This format is used over field "Prefix/suffix select" to determine if the alpha part (if present) of a serial number should prefix or suffix the numeric part of the serial number.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "015" and save it to the printer's label store. The label will contain one text element containing the data "A" and a counter element.

Sent to printer: 1B 53 30 31 35 41 1B 6A 31 4E 30 31 30 39 31 4E 4E 30 30 30 30
30 30 30 4E 04

Response from printer: 06

Start Bold Characters and Logos – 'k' 6B_h

After this command is entered, all characters and logos entered will be printed double width (each vertical stroke is printed twice). This is additional to any global commands set at the time of printing. It remains in force until the stop bold characters command is found.

Set String Format

	ESC	Command ID
ASCII	ESC	k
HEX	1B	6B

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

The string sent to the printer in the example below also contains command 53 and 76. This will create a label named "016" and save it to the printer's label store. The label will contain three text elements. The first text element will contain the data "A" and will not be bold. The second text element will contain the data "BC" and will be bold. The third text element will contain the data "D" and will not be bold.

Sent to printer: 1B 53 30 31 36 41 1B 6B 42 43 1B 76 44 04

Response from printer: 06

Insert Logo – 'm' 6D_h

This command inserts a monochrome bitmap (black and white .bmp) into a label. The bitmap must have a single character name. Domino logo files from older printers can be converted to bitmaps using the Domino Logo Editor.

Notes: (1) Before implementing a logo, the character height must be set to an appropriate height for the type of printer. Character height should be restored to the required value following logo entry. In the HEADER information for the logo there is a description field. The description field must contain a single character. This character is used in the protocol to insert the required logo.

(2) The number of logos per label is limited to 16.

Set String Format

	ESC	Command ID	Logo Name
ASCII	ESC	m	A to z or 1 to 9
HEX	1B	6D	41 to 7a or 30 to 39

Logo Name: One character to identify the logo.
A to z or 1 to 9 (41 to 7a or 30 to 39)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "017" and save it to the printer's label store. The label will contain a text element containing the data "A". The label will also include a logo named "1". To allow this string to work, a monochrome bitmap logo with the file name "1" must be saved in the printer's memory.

Sent to printer: 1B 53 30 31 37 41 1B 6D 31 04

Response from printer: 06

Insert Date/Time – 'n' 6E_n

This command causes a specified date or time field to be inserted into the label. The date or time field will be inserted at the current line and column position with the current character attributes. The printed value will be derived from the printer's real time clock data. A maximum of 4 entries of each field type is permitted in each label, i.e. 1 per offset.

Set String Format

- Notes: (1) To insert a Date/Time field with more than one character, repeat the, Clock ID and Date/Time Character before entering the EOT character.
- (2) Week numbering conforms to BS 4760 : 1971. (ISO/R 2015 “Numbering of Weeks”)
- (3) Options “Month”, “Day” and “Alpha Hour” can be set using the commands INIT_DATE_MONTHS, INIT_DAYS, and INIT_ALPHA.
- (4) Options “Month”, “Day” and “Alpha Hour” cannot be embedded within a barcode.
- (5) The number of clock fields per label is limited to 16.

	ESC	Command ID	Clock ID	Date/Time Character
ASCII	ESC	n	1 to 4	A to P (See Date/Time Character Table)
HEX	1B	6E	31 to 34	41 to 50 (See Date/Time Character Table)

Clock ID: One Byte to identify the clock.
 1 (31) = Clock 1
 2 (32) = Clock 2
 3 (33) = Clock 3
 4 (34) = Clock 4

Date/Time Character: One character to define the type of date/time character value that will be printed. See the "Date/Time Character" table below for full details.

Date/Time Character			
ASCII	HEX	Description	Printed Range
A	41	Day of Month as two Bytes.	01 to 31
B	42	Day of Year as three Bytes.	001 to 366
C	43	Julian year as 1 Byte. (Year of Decade)	0 to 9
D	44	Year as two Bytes. (Year of Century)	00 to 99
E	45	Year as four Bytes.	1979 to 2199
F	46	Month Number as two Bytes.	01 to 12

Date/Time Character			
ASCII	HEX	Description	Printed Range
G	47	Month as three characters. (from command 'D' 44 _h)	JAN to DEC (or user defined)
H	48	Hours as two Bytes. (Hours of the Day)	00 to 23
I	49	Quarter hours as two Bytes. (from 00:00:00)	01 to 96
J	4A	Day as three characters. (from command 'E' 45 _h)	MON to SUN (or user defined)
K	4B	Week number as two Bytes. (to BS47450)	01 to 53
L	4C	Day number as one Byte. (from Mon to Sun)	1 to 7
M	4D	Minutes as two Bytes.	00 to 59
N	4E	Seconds as two Bytes.	00 to 59
O	4F	Alpha Hour as one character. (from command 'Y' 59 _h)	A to Z (or user defined)
P	50	Julian Day as three Bytes. (Feb 29 = Day)	001 to 366

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "018" and save it to the printer's label store. The label will contain 16 different date/time elements.

Sent to printer: 1B 53 30 31 38 1B 6E 31 41 20 1B 6E 31 42 20 1B 6E 31 43 20 1B
6E 31 44 20 1B 6E 31 45 20 1B 6E 31 46 20 1B 6E 31 47 20 1B 6E
31 48 20 1B 6E 31 49 20 1B 6E 31 4A 20 1B 6E 31 4B 20 1B 6E 31
4C 20 1B 6E 31 4D 20 1B 6E 31 4E 20 1B 6E 31 4F 20 1B 6E 31
50 20 04

Response from printer: 06

Offset Clock – 'o' 6F_h

This command applies a user-supplied positive offset to date and time fields in the label.

Set String Format

	ESC	Command ID	Clock ID Number	Offset Type	Offset Value
ASCII	ESC	o	1 to 4	A, C, E or F	000 to 366
HEX	1B	6F	31 to 34	41, 43, 45 or 46	33030 to 333636

Clock ID Number: One Byte clock selector.

- 1 (31) = Clock 1
- 2 (32) = Clock 2
- 3 (33) = Clock 3
- 4 (34) = Clock 4

Offset Type: One Byte offset type selector.

- A (41) = Years
- C (43) = Days
- E (45) = Hours
- F (46) = Minutes

Offset Value: Three Byte offset value.

- Range if "Offset Type Value" is Years: 000 to 099 (303030 to 303939)
- Range if "Offset Type Value" is Days: 000 to 366 (303030 to 333636)
- Range if "Offset Type Value" is Hours: 000 to 023 (303030 to 303233)
- Range if "Offset Type Value" is Minutes: 000 to 059 (303030 to 303539)

Notes: (1) *Before printing a label that includes embedded clock fields, the printer generates up to four label specific clocks by applying any clock offsets encountered in the label to the printer's system clock. The label specific clocks are then used to update any relevant clock strings in the print buffer.*

- (2) *Current year and any year offset must be taken into consideration in order to allow for offset periods which straddle one or more leap days.*
- (3) *Offset date/time command fields may occur at any point within the stored print label.*
- (4) *Offsets reset to zero when another label is sent unless a new offset is requested in that label.*

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53 and 6E. This will create a label named "019" with a date element that displays the year as four Bytes. The label will be saved in the printer's label store. The 6F command in the example below will offset the date element by +20 years.

Sent to printer:	1B 53 30 31 39 1B 6E 31 45 1B 6F 31 41 30 32 30 04
Response from printer:	06

Insert Shift Code (Time Conditional Print String) – 'p' 70_h

This embedded format command allows the user to define a sequence of characters to be substituted in the label if the time of printing falls within a pre-defined pair of limits. This is useful for marking products on a work shift basis. A maximum of 5 characters is allowed in a time conditional string and up to 4 strings can be specified for each label. Time conditional strings may be grouped together for use as alternatives which are substituted at the time of printing.

- Notes: (1) Where time conditional fields occur in the same place in the label, they will be interpreted as time conditional alternative print strings and the length of the longest one will be used to reserve print buffer space. In this case, if the time limit associated with the time conditional strings overlap each other, the string with the lower identity number will be the one printed.
- (2) Start and end times will be compared at the time of printing with the printer's real time clock hours and minutes. This determines whether a time conditional string is to be substituted into the printed label.
- (3) Outside of the active time limits for any of the entered time conditional strings their positions in the printed label will be printed as spaces to the same string length.
- (4) Time conditional strings cannot be embedded within a barcode.

Set String Format

	ESC	Command ID	Number of Alternative Strings	Time Conditional String ID	Start Time
ASCII	ESC	p	1 to 4	1 to 4	0000 to 2359
HEX	1B	70	31 to 34	31 to 34	30303030 to 32333539

End Time	String Length	Characters to be Printed
0000 to 2359	1 to 5	Any legal character (As String Length)
30303030 to 32333539	31 to 35	Any legal character (As String Length)

- Number of Alternate Strings: One Byte, number of alternate strings.
Range: 1 to 4 (31 to 34)
- Time Conditional String ID: One character to identify the time conditional string.
Range: 1 to 4 (31 to 34)
- Start Time: Four characters that define the start time.
Range: 0000 to 2359 (30303030 to 32333539)
- End Time: Four characters that define the end time.
Range: 0000 to 2359 (30303030 to 32333539)

LABEL FORMATTING COMMANDS

String Length: One character that defines the length of the print string.
Range: 1 to 5 (31 to 35)

Characters to be Printed: Characters to be printed, the number of characters depends on the string length value. Any legal characters can be used.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The string sent to the printer in the example below also contains command 53. This will create a label named "020" that will be saved in the printer's label store. The label will contain a shift code element that will print the code "Aa" between the hours 00:00 to 11:59. Outside of the hours 00:00 to 11:59 nothing will be printed.

Sent to printer: 1B 53 30 32 30 1B 70 31 31 30 30 30 30 31 31 35 39 32 41 61 04


Response from printer: 06

Insert Barcode – 'q' 71_h

This command will cause the following text to be printed in bar encoded format until a matching terminating command is encountered. The barcode must be terminated with the relevant terminator.

Set String Format

	ESC	Command ID	Barcode Type	Barcode Data	ESC	Command ID
ASCII	ESC	q	See Barcode Type Table.	See Barcode Characteristics.	ESC	q
HEX	1B	71	See Barcode Type Table.	See Barcode Characteristics.	1B	71



Barcode End
0
30

Note: Before entering a barcode start command, the character height must be set to the maximum height applicable to the type of printer. The character height should be restored to the required value following entry of the corresponding barcode end command.

Barcode Type

Barcode Type	ASCII	HEX
Code 39	1	31
2of 5 Interleaved, No checksum	2	32
USPS (Not yet implemented)	3	33
EAN/UPC	4	34
Codabar (Not yet implemented)	5	35
Code 128 code set B	6	36
2 of 5 Interleaved, Modulus 10 factor 3 checksum	7	37
Code 128 Auto code set ABC	8	38
Code 93 (Automatic calculation of check Bytes)	9	39

Barcode Characteristics

Code 39

Character set: 0 to 9 A to Z space - . \$ / + % start / stop characters (see notes).

Element widths: narrow 1, wide 3 (See Note).

Nominal widths: Each character consists of 3 wide + 5 narrow.

Notes: (1) For display purposes, the start/stop character is usually shown as an asterisk “”.*

(2) The inter character gap is set to 1 narrow space.

(3) The default barcode ratio and inter character gap are set to 2:1 and 1:1. The module width can be changed using the barcode thickness command.

Interleave 2 of 5

Character set: 0 to 9, start, stop (generated by the Ink Jet).

Element widths: narrow = 1, wide = 3 (See Note).

Nominal widths: start pair 8, Byte pair 18, stop pair 10.

Note: The label starts with a pair of start characters, 8 elements. All Bytes are printed as pairs, therefore there must be an even number of Bytes. If an uneven number is specified then add a leading zero. The label ends with a pair of stop characters, 10 elements.

Codabar (Not Yet Implemented)

Character set: 0 to 9 - \$: / . + and 4 start / stop characters.

Element widths: narrow = 1, wide = 3.

Nominal widths: 0-9 - \$ 11 elements all others 13 elements.

Code 128

Character set is codeset B, alphanumeric and punctuation.

A modulo-103 check digit is added by default.

Code 128 Auto

Character set is codeset A, B, C, alphanumeric and punctuation. The codeset selection is handled automatically by the printer.

A modulo-103 check digit is added by default.

EAN/UPC

Character set: 0 to 9

Element widths: narrow = 1, med.1 = 2, med.2 =3, wide = 4

Nominal widths: 7 elements.

EAN 8 \$ [5 dig. manf. code] [2 dig. art. code] [chk dig.] \$

EAN13 @ [nat.dig.] [6 dig.manf. code] [5 dig.art. code] [chk.dig] @

UPC12 & [6 dig. manf. code] [5 dig. art. code] [chk.dig.] &

Notes: (1) Logos, time conditional clock and clock fields “GG” “JJ” and “O” are not allowed.

(2) With EAN and UPC bar codes the check digit must be included as the software does not calculate it. However, when the data is read back via comms it will not return the checksum, just the data.

(3) Only simple numbers are allowed in EAN and UPC barcodes. No clock, serial numbers or updateable text fields etc.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "021" that will be saved in the printer's label store. The label will contain a Code 128 barcode with the data "1234567890".

Sent to printer:	1B 53 30 32 31 1B 71 38 31 32 33 34 35 36 37 38 39 30 1B 71 30 04
Response from printer:	06

Line Separator – 'r' 72_h

This command will cause the text that follows to be entered on the following line starting at the first unoccupied column position.

Set String Format

	ESC	Command ID
ASCII	ESC	r
HEX	1B	72

Note: After receiving a line separator character, the software will revert to the default of non-bold first character set. Therefore, an attribute set in one line must be set again if required for the next line.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53 and 75. This will create a label named "022" that will be saved in the printer's label store. The label will contain three text elements on different column positions. The first text element contains the data "A", the second text element contains the data "B" and the third text element contains the data "C".

Sent to printer: 1B 53 30 32 32 1B 75 31 41 1B 72 42 1B 72 1B 75 32 43 04

Response from printer: 06

Set Character Height – 'u' 75_h

Characters entered following this command will be printed with the specified height if valid and available. Not all print formats have all character sets present.

Set String Format

	ESC	Command ID	Character Height
ASCII	ESC	u	1 to maximum defined print format.
HEX	1B	75	31 to maximum defined print format.

Note: This is a 1-based index (starts at 1 for 1st item). The drop height depends on the Label Format and what is defined in it as the 1st, 2nd height etc. There is no knowledge of drop height, just ordinal height. Make sure that a mixed Label Format is selected if you wish to use a character height other than 1.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53 and 72. This will create a label named "022" that will be saved in the printer's label store. The label will contain three text elements on different column positions.

The first text element contains the data "A".

The second text element contains the data "B", which will all be printed with the default first ordinal character height.

The third text element contains the data "C". However, the third element will be printed using the second ordinal height.

Sent to printer: 1B 53 30 32 32 1B 75 31 41 1B 72 42 1B 72 1B 75 32 43 04

Response from printer: 06

Stop Bold Characters – 'v' 76_h

Characters entered following this command will be printed single width (each vertical stroke is printed once). This has no effect on any additional global commands in force at the time of printing.

Set String Format

	ESC	Command ID
ASCII	ESC	v
HEX	1B	76h

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53 and 6B. This will create a label named "016" and save it to the printer's label store. The label will contain three text elements. The first text element will contain the data "A" and will not be bold. The second text element will contain the data "BC" and will be bold. The third text element will contain the data "D" and will not be bold.

Sent to printer: 1B 53 30 31 36 41 1B 6B 42 43 1B 76 44 04

Response from printer: 06

Insert Language Date/Time – 'w' 77_h

This command is similar to the Insert Date/Time command on [page 7-15](#), but has an additional field to define which counting format is used.

Set String Format

- Notes: (1) To insert a Date/Time field with more than one character, repeat the, Clock ID and Date/Time Character and Language Type before entering the EOT character.
- (2) Week numbering conforms to BS 4760 : 1971. (ISO/R 2015 “Numbering of Weeks”)
- (3) Options “Month”, “Day” and “Alpha Hour” can be set using the commands 'D', 'E', and 'Y'.
- (4) Options “Month”, “Day” and “Alpha Hour” cannot be embedded within a barcode.
- (5) The number of clock fields per label is limited to 16.
- (6) For a printer equipped with a duo print head, the limit described in note (5) applies across both regions.

	ESC	Command ID	Clock ID	Date/Time Character
ASCII	ESC	w	1 to 4	A to P (See Date/Time Character Table)
HEX	1B	77	31 to 34	41 to 50 (See Date/Time Character Table)

Language Type
0, 1 or 2
30, 31 or 32

Clock ID: One Byte to identify the clock.
 1 (31) = Clock 1
 2 (32) = Clock 2
 3 (33) = Clock 3
 4 (34) = Clock 4

Date/Time Character: One Byte to define the type of date/time character value that will be printed. See the "Date/Time Character" table below for full details.

Language Type: One Byte that defines the language type.
 0 (30) = Gregorian
 1 (31) = Jalali
 2 (32) = Farsi

LABEL FORMATTING COMMANDS

Date/Time Character			
ASCII	HEX	Description	Printed Range
A	41	Day of Month as two Bytes.	01 to 31
B	42	Day of Year as three Bytes.	001 to 366
C	43	Julian year as 1 Byte. (Year of Decade)	0 to 9
D	44	Year as two Bytes. (Year of Century)	00 to 99
E	45	Year as four Bytes.	1979 to 2199
F	46	Month Number as two Bytes.	01 to 12
G	47	Month as three characters. (from command 'D' 44 _h)	JAN to DEC (or user defined)
H	48	Hours as two Bytes. (Hours of the Day)	00 to 23
I	49	Quarter hours as two Bytes. (from 00:00:00)	01 to 96
J	4A	Day as three characters. (from command 'E' 45 _h)	MON to SUN (or user defined)
K	4B	Week number as two Bytes. (to BS47450)	01 to 53
L	4C	Day number as one Byte. (from Mon to Sun)	1 to 7
M	4D	Minutes as two Bytes.	00 to 59
N	4E	Seconds as two Bytes.	00 to 59
O	4F	Alpha Hour as one character. (from command 'Y' 59 _h)	A to Z (or user defined)
P	50	Julian Day as three Bytes. (Feb 29 = Day)	001 to 366

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Insert Bitmap – 'x' 78_h

This command causes the specified pre-stored bitmap to be inserted into the print label starting at the current line and column position. This is similar to the insert logo command on [page 7-14](#) with the difference that any bitmap with a name up to five characters can be inserted.

Note: Prior to implementing a bitmap, character height must be set to the appropriate height for the type of printer. Character height should be restored to the required value following bitmap entry.

Set String Format

	ESC	Command ID	Bitmap Name Length	Bitmap Name
ASCII	ESC	x	1 to 5	0 to 9 and A to z (1 to 5 characters)
HEX	1B	78	31 to 35	30 to 39 and 40 to 7A (1 to 5 characters)

Bitmap Name Length: 1 Byte to define the length of the bitmap name.
Range: 1 to 5 (31 to 35)

Bitmap Name: The name of the bitmap file, 1 to 5 characters long.
Characters 0 to 9 (30 to 39) and A to z (40 to 7A) can be used.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "025" and save it to the printer's label store. A bitmap file named 12345 will be inserted into the label. A bitmap file named 12345 must be saved in the printer's memory for this string to work.

Sent to printer: 1B 53 30 32 35 1B 78 35 31 32 33 34 35 04

Response from printer: 06

2D Codes – 'z' 7A_h

This command will cause the following text to be printed in 2-D code format until a matching terminating command is encountered. The 2-D code must be terminated with the relevant terminator. Unlike the barcode command each 2-D code has its own independent attribute block. Up to 4 different 2-D codes can be inserted into a label.

Notes: (1) Unicode cannot currently be embedded in the 2-D code.

- (2) The data type parameter is ignored and will be calculated from the printer's barcode library.
- (3) QR Codes must be square. For example, the Columns and Rows values must be the same.
- (4) When Columns = 00 (3030) and Rows = 00 (3030) the printer will choose the largest possible size for the 2D code that fits the currently selected label format.
- (5) Certain combinations of size and magnification, (E.g. 16x48 and x4) are unavailable. Both 0 (30) and 1 (31) denote x1 magnification (default) to the 2D code.
- (6) When inserting a 2D code, you need to first select an appropriate ordinal height with the 'u' 75h (Set Character Height) command, which can accommodate the 2D code's height.

Set String Format

	ESC	Command ID	Barcode Type	Data Type	Error Correction
ASCII	ESC	z	1, 2 or 3	0 to 6	00 to 10 or 26
HEX	1B	7A	31, 32 or 33	30 to 36	3030 to 3130 or 3236

Rows	Column	Magnification	Vertical Alignment	Unused 1
00 to 99	00 to 99	1 to 4	0 or 1	0
3030 to 3939	3030 to 3939	30 to 34	30 or 31	30

Unused 2	Data
0	Any Valid Characters
30	Any Valid Characters

Code Terminator		
ESC	Command ID	Barcode Type
ESC	z	0
1B	7A	30

LABEL FORMATTING COMMANDS

Barcode Type: One Byte to specify the barcode type or end the dot code.
0 (30) = Barcode terminator
1 (31) = Data Matrix
2 (32) = QR Code
3 (33) = ISS Dot Code (Ax-Series Only)

Data Type: One Byte to specify the data type.

Data Matrix:

0 (30) = Numeric only
1 (31) = Alpha only
2 (32) = Alpha numeric
3 (33) = Upper case only
4 (34) = Lower case only
5 (35) = Punctuation
6 (36) = 8 bit ASCII

QR Code:

1 (31) = Model 1
2 (32) = Model 2

ISS Dot Code (Ax-Series Only):

0 (30) = ASCII (To be verified)

Error Correction: Two Bytes to specify the error correction code.

Data Matrix:

00 (3030) = 000
01 (3031) = 010
02 (3032) = 040
03 (3033) = 050
04 (3034) = 060
05 (3035)
06 (3036) = 080
07 (3037)
08 (3038) = 100
10 (3130) = 120
26 (3236) = 200

QR Code:

00 (3030) = L
01 (3031) = M
02 (3032) = Q
03 (3033) = H

ISS Dot Code (Ax-Series Only):

00 (3030) = 000

LABEL FORMATTING COMMANDS

Rows: Two Bytes to specify the number of rows. QR Codes must be square, i.e. the Rows and Column value must be the same.

Data Matrix:
00 to 99 (3030 to 3939)

QR Code:
21, 25 or 29 (3231, 3235 or 3239)

ISS Dot Code (Ax-Series Only):
00 to 99 (3030 to 3939)

Column: Two Bytes to specify the number of columns. QR Codes must be square, i.e. the Rows and Column value must be the same.

Data Matrix:
00 to 99 (3030 to 3939)

QR Code:
21, 25 or 29 (3231, 3235 or 3239)

ISS Dot Code (Ax-Series Only):
00 to 99 (3030 to 3939)

Magnification: One Byte magnification value. Certain combinations of dotcode sizes and magnification are unavailable. e.g. 16x48 and x4. Both 0 and 1 denote a x1 magnification (default) to the 2D code.

Datamatrix:
0 to 4 (30 to 34)


QR Code:
0 to 1 (30 to 31)

ISS Dot Code (Ax-Series Only):
0 to 2 (30 to 32)

Vertical Alignment: One Byte field alignment value. This value will align the 2D code bitmap to the top or bottom.

0 (30) = Align to top (default)
1 (31) = Align to bottom

The following example shows a 2D code of 10 rows aligned at the top and bottom respectively.



Unused 1: One Byte, unused field, always set to 0 (30).

Unused 2: One Byte, unused field, always set to 0 (30).

Data: <date for 2D Code>

Example – Data Matrix

	ESC	Command ID	Store Number	ESC	Select 2nd font size of 16 drops
ASCII	ESC	OQ	001	ESC	u2
HEX	1B	4F51	303031	1B	7532

ESC	Command ID	Start	Numeric Only	ECC of 200
ESC	z	1	0	26
1B	7A	31	30	3236

Number of Rows	Number of Columns	Magnification	Align to Top	Unused 1
16	16	1	0	0
3136	3136	31	30	30

Unused 2	Barcode Data	ESC	Command ID	Stop
0	1234	ESC	z	0
30	31323334	1B	7A	30

Return Cursor to Known Position
ESC u 1 ESC r ESC r ESC r
1B75311B721B721B72

Data Matrix also supports **FNC1** (Function Code One) character in GSI codes. This is supported by inserting the **FNC1** character data in the **Barcode Data** field above. Format of **FNC1** character data is:

FNC1	Application Identifier (AI)	Data (in format of AI specified)
~1	01	00012345678905
7E31	3031	3030303132333435363738393035

More than one FNC1 character can be specified in the Barcode Data section. Within each FNC1 character, multiple Application Identifier (AI) can be specified, together with its corresponding Data.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "026" and save it to the printer's label store. A data matrix barcode containing the data "1234" will be inserted into the label.

Sent to printer: 1B 53 30 32 36 1B 7A 31 30 32 36 31 36 31 36 31 30 30 30 31 32
 33 34 1B 7A 30 04

Response from printer: 06

Example – QR Code

	ESC	Command ID	Store Number	ESC	Select 4th font size of 16 drops
ASCII	ESC	OQ	001	ESC	u4
HEX	1B	4F51	303031	1B	7534

ESC	Command ID	Start	Model	Error Level
ESC	z	2	2	00
1B	7A	32	32	3030

Number of Rows	Magnification	Align to Top	Unused 1	Unused 2
29	1	0	0	0
3239	31	30	30	30

Unicode Data = 脛01	ESC	Command ID	Stop
814000300031	ESC	z	0
38313430 30303330 30303331	1B	7A	30

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer’s response.

The string sent to the printer in the example below also contains command 53. This will create a label named “026” and save it to the printer’s label store. A QR code containing the data “1234” will be inserted into the label.

Sent to printer: 1B 53 30 32 36 1B 7A 32 32 30 30 32 39 32 39 31 30 30 30 38 31
34 30 30 30 33 30 30 30 33 31 1B 7A 30 04

Response from printer: 06

Insert Updatable Text Field – '|' 7C_h

This command inserts an updatable text field into the label. The field can be populated with data sent via Ethernet or RS232 using the External Protocol to fill the serial buffer with data.

Set String Format

	ESC	Command ID	Text Field Length	External Data Delimiter	Offset Within External Data Buffer
ASCII	ESC		0001 to 1024	00 to 7D (HEX)	0000 to 1023
HEX	1B	7C	30303031 to 31303234	3030 to 3744	30303030 to 31303233

Index	Comms Method
01 to 16	0 or 1
3031 to 3136	30 or 31

Text Field Length Four Bytes to specify the updatable text field length.
Range: 0001 to 1024 (30303031 to 31303234)

External Data Delimiter Two Bytes in hex that specify the external data delimiter. 2C (3243) will insert a comma. 00 (3030) implies that the external data is not delimited. If set to 00 (3030) then the offset will be used to extract the set of data from the external data buffer.
Range: 00 to 7D (3030 to 3744).

Offset Within External Data Buffer: Four Bytes that specify the offset within external data buffer.
Range: 0000 to 1023 (30303030 to 31303233)

Index: Two Bytes that specify the index, used for delimited data only.
Range: 01 to 16 (3031 to 3136).

Comms Method One Byte that specifies the method used to fill the external data buffer with data.
0 (30) = RS232
1 (31) = Ethernet


Example 1

Set the field up inside a label in the printer. Normally used for a label with a single updatable text field.

The external data sent to the buffer is 0123456.

The data printed is 123.

	ESC	Command ID	Text Field Length	Delimiter	Offset within external data buffer
ASCII	ESC		0003	00	0001
HEX	1B	7C	30303033	3030	30303031



Index	Comms Method
01	1
3031	31

Text Field Length: Set to 0003.

Delimiter: Set to 00, no delimiter.

Offset within external data buffer: Set to 0001 to ignore the first character and start from the second.

Index: Set to 01, default as it is not used in this example.

Comms Method: Set to 1 for Ethernet.


Example 2

Set the field up inside a label in the printer. Normally used for a label with multiple updatable text fields.

The external data sent to the buffer is 0123,456,ABCD.

The data that gets printed is ABCD.

	ESC	Command ID	Text Field Length	Delimiter	Offset within external data buffer
ASCII	ESC		0004	2C	0000
HEX	1B	7C	30303034	3243	30303030



Index	Comms Method
03	1
3033	31

Text Field Length: Set to 0004.

Delimiter: Set to 2C, for comma.

Offset within external data buffer: Set to 0000 as it is not used in this example.

Index: Set to 03.

Comms Method: Set to 1 for Ethernet.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "027" and save it to the printer's label store. A three character long text field that can be updated via Ethernet will be inserted into the label.

Sent to printer: 1B 53 30 32 37 1B 7C 30 30 30 33 30 30 30 30 31 30 31 31 04

Response from printer: 06

Insert Language Date/Time – '}' 7D_h

This command is similar to the language date/time command ('W' 77_h) on [page 7-27](#), but has an additional field to define which calendar type is used.

Set String Format

- Notes: (1) Week numbering conforms to BS 4760 : 1971. (ISO/R 2015 “Numbering of Weeks”)
 (2) Options “Month”, “Day” and “Alpha Hour” can be set using the commands 'D', 'E', and 'Y'.
 (3) Options “Month”, “Day” and “Alpha Hour” cannot be embedded within a barcode.
 (4) The number of clock fields per label is limited to 16.
 (5) For a printer equipped with a duo print head, the limit described in note (4) applies across both regions.

	ESC	Command ID	Clock ID	Date/Time Character
ASCII	ESC	}	1 to 4	Refer to the table on page 7-41 .
HEX	1B	7D	31 to 34	Refer to the table on page 7-41 .

Language Type	Calendar type
0, 1 or 2	0, 1 or 2
30, 31 or 32	30, 31 or 32

Clock ID: One Byte to identify the clock.
 1 (31) = Clock 1
 2 (32) = Clock 2
 3 (33) = Clock 3
 4 (34) = Clock 4

Date/Time Character: One Byte to define the type of date/time character value that will be printed. See the “Date/Time Character” table below for full details.

Language Type: One Byte that defines the language type.
 0 (30) = Latin based
 1 (31) = Arabic
 2 (32) = Farsi

Calendar Type: One Byte that defines the calendar type.
 0 (30) = Gregorian
 1 (31) = Jalali
 2 (32) = Hijri

LABEL FORMATTING COMMANDS

Date/Time Character			
ASCII	HEX	Description	Printed Range
A	41	Day of Month as two Bytes.	01 to 31
B	42	Day of Year as three Bytes.	001 to 366
C	43	Julian year as 1 Byte. (Year of Decade)	0 to 9
D	44	Year as two Bytes. (Year of Century)	00 to 99
E	45	Year as four Bytes.	1979 to 2199
F	46	Month Number as two Bytes.	01 to 12
G	47	Month as three characters. (from command 'D' 44 _h)	JAN to DEC (or user defined)
H	48	Hours as two Bytes. (Hours of the Day)	00 to 23
I	49	Quarter hours as two Bytes. (from 00:00:00)	01 to 96
J	4A	Day as three characters. (from command 'E' 45 _h)	MON to SUN (or user defined)
K	4B	Week number as two Bytes. (to BS47450)	01 to 53
L	4C	Day number as one Byte. (from Mon to Sun)	1 to 7
M	4D	Minutes as two Bytes.	00 to 59
N	4E	Seconds as two Bytes.	00 to 59
O	4F	Alpha Hour as one character. (from command 'Y' 59 _h)	A to Z (or user defined)
P	50	Julian Day as three Bytes. (Feb 29 = Day)	001 to 366

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

This string will set the clocks with Arabic language using Jalali calendar type.

Sent to printer: 1B 53 30 30 31 20 63 6C 6F 63 6B 20 31 3A 20 1B 7D 31 41 31 32
 20 1B 7D 31 42 31 32 20 1B 7D 31 43 31 32 20 1B 7D 31 44 31 32
 20 1B 7D 31 45 31 32 20 1B 7D 31 46 31 32 20 1B 7D 31 47 31 32
 20 1B 7D 31 48 31 32 20 1B 7D 31 49 31 32 20 1B 7D 31 4A 31 32
 20 1B 7D 31 4B 31 32 20 1B 7D 31 4C 31 32 20 1B 7D 31 4D 31
 32 20 1B 7D 31 4E 31 32 20 1B 7D 31 4F 31 32 20 1B 7D 31 50 31
 32 20 04

Response from printer: 06

Insert a Thin Space of One Stroke – '~N' 7E_h 4E_h

This command inserts a one stroke wide space.

Set String Format

	ESC	Command ID
ASCII	ESC	~N
HEX	1B	7E4E

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below also contains command 53. This will create a label named "028" and save it to the printer's label store. Two text elements that both contain the data "E" will be added to the label. A one stroke space will be inserted between the two text elements.

Sent to printer: 1B 53 30 32 38 45 1B 7E 4E 45 04

Response from printer: 06

THIS PAGE INTENTIONALLY LEFT BLANK

PART 8 : NEGATIVE ACKNOWLEDGEMENT ERROR CODES

CONTENTS

	Page
NEGATIVE ACKNOWLEDGEMENT ERROR CODES	8-3

THIS PAGE INTENTIONALLY LEFT BLANK

NEGATIVE ACKNOWLEDGEMENT ERROR CODES

Negative acknowledgement error codes consist of 3 ASCII digits which are transmitted to the controller following the negative acknowledgement control character.

ASCII	Explanation
000	Software error (this error code should never occur)
001	Specified character set not present
002	Invalid command header, <ESC> expected
003	Unrecognised command code following <ESC>
004	Unexpected characters occurred before <EOT>
005	Invalid head selector
006	Out of range print acknowledgement character
007	Command parameter out of permitted range
008	Print label number out of range
009	Syntax error
010	Print label too long for label store
011	Print label too long for print buffer
012	Invalid embedded format command
013	Invalid character in print label
014	Invalid number of lines in print label
015	Invalid character size specified in print label
016	Cannot load label
017	Specified print label number is invalid
018	Label assigned to another product detector
019	Cannot assign logo to single line head
020	Command not implemented
021	Logo ID invalid for specified character set
022	Invalid character set specified
023	Invalid checksum field
024	Checksum error
025	No character set RAM available
026	Character set download error
027	Command rejected printing disabled
028	Clock ID out of range

NEGATIVE ACKNOWLEDGEMENT ERROR CODES

ASCII	Explanation
029	Invalid clock field selector
030	Duplicate clock field specified
031	Time-conditional string has duplicate time field
032	Serial number out of range
033	Serial number increment value too big
034	Identifier out of range
035	Numeric field too long
036	Non-numeric character encountered
037	Both numeric and pre/suffix lengths are zero
038	Non-alpha character encountered
039	Invalid step order selected
040	Invalid product detector identity specified
041	Too many time-conditional strings specified
042	Time-conditional string identifier out of range
043	Time-conditional string time limit out of range
044	Time-conditional string too long
045	Invalid barcode type specified
046	Command invalid in barcode string
047	Maximum character size must be selected first
048	Invalid character for barcode type
049	Invalid character count for barcode
050	The printer is busy with Auto repeat de-assert photocell
051	An internal printer error caused the command not to be processed
052	The requested file could not be found
301	There are too many MRC
401	Wrong language ID out of range
402	Ignore send acknowledge
403	MRC exceed maximal width
404	Invalid 2D code type
405	Invalid 2D code format
406	Invalid 2D code ECC

NEGATIVE ACKNOWLEDGEMENT ERROR CODES

ASCII	Explanation
407	Invalid 2D code rows number
408	Invalid 2D code columns number
409	Invalid 2D code magnification factor
410	Invalid 2D code alignment

THIS PAGE INTENTIONALLY LEFT BLANK

PART 9 : EXTENDED CODENET COMMANDS

CONTENTS

	Page
EXTENDED CODENET COMMANDS	9-3
Send Data to FiFo Buffer to fill an Updatable Text Field – 'OE' 4Fh 45h	9-3
Set String Format	9-3
Response to Set	9-4
Clear String Format.....	9-5
Response to Clear	9-5
Set and Response String Examples 1	9-5
Set and Response String Examples 2	9-5
Print Height – 'OH' 4Fh 48h	9-6
Set String Format	9-6
Response to Set	9-6
Query String Format	9-6
Response to Query	9-6
Set and Response String Examples	9-6
Query and Response String Examples	9-7
Store Bitmap – 'OL' 4Fh 4Ch	9-8
Set String Format	9-8
Set and Response String Examples	9-9
Store Label with variable length name – 'OM' 4Fh 4Dh	9-10
Set String Format	9-10
Set String Example	9-10
Response to Set	9-10
Query String Format	9-11
Response to Query	9-11
Set and Response String Examples	9-11
Query and Response String Examples	9-11
Retrieve a Label with a Variable Length Name from the Label Store and put Online – 'ON' 4Fh 4Eh	9-12
Set String Format	9-12
Set String Example	9-12
Response to Set	9-12
Query String Format	9-13
Response to Query	9-13
Set and Response String Examples	9-13
Query and Response String Examples	9-13
Configure FiFo Buffer to Receive External Data – 'OP' 4Fh 50h	9-14
Set String Format	9-14
Response to Set	9-15
Query String Format	9-15
Response to Query	9-15
Set and Response String Examples	9-15
Query and Response String Examples.....	9-16
Download Label without Save – 'OQ' 4Fh 51h	9-17
Set String Format	9-17
Response to Set	9-17
Query String Format	9-17
Response to Query	9-17

Set and Response String Examples.....9-18
 Query and Response String Examples9-18
 Sequence Ink Jet on and off – 'OS' 4Fh 53h9-19
 Set String Format9-19
 Response to Set9-19
 Query String Format9-19
 Response to Query.....9-20
 Set and Response String Examples.....9-21
 Query and Response String Examples9-21
 External Data Queue Expired Entries Config – 'OV' 4Fh 56h9-22
 Set String Format9-22
 Response to Set9-22
 Query String Format9-22
 Response to Query9-23
 Set and Response String Examples9-23
 Query and Response String Examples9-23
 Get Current Status – 'O1' 4Fh 31h9-24
 Query String Format9-24
 Response to Query9-24
 Query and Response String Examples9-24
 Get Current Alert – 'O2' 4Fh 32h9-25
 Query String Format9-25
 Response to Query9-25
 Query and Response String Examples.....9-26
 Alert Status Table9-27

0

EXTENDED CODENET COMMANDS

A previously unused command character 'O' (4FH) has been used to access the extended commands. This set of the extended commands is only available on A-Series and Ax-Series printers.

Send Data to FiFo Buffer to fill an Updatable Text Field – 'OE' 4F_h 45_h

For serial connections it is only possible to have one connection per port. For that reason it is not possible to use Codenet together with data streaming through the same port. To fill an updatable text field, data must be sent per print via Codenet using this command.

Use this command in conjunction with Command 4F50 (OP) which sets up the FIFO buffer parameters. The command also allows the external data queues and historic logs to be cleared. This command is an alternative way to send data to the FIFO buffer. The command OE allows external data to be sent to the printer, storing the external data block in the RS232 serial or Ethernet/TCP buffer, depending on how Codenet is configured to accept connections.

The other method is to use External Data Capture (EDC) to stream data to the Ethernet/TCP FIFO buffer (EDC TCP) on Port 16000 or to the Serial FIFO buffer (EDC Serial) through RS232 serial.

- (1) *Clear the buffer before sending data to ensure nothing that was in the buffer is printed.*
- (2) *This command only works with ASCII data. To use Unicode the data must be streamed into the printer's Ethernet Port.*
- (3) *The buffer in which the data is sent to is based on your connection to the printer (i.e. if through RS232 serial, the data goes to the serial buffer and if through Ethernet/TCP, data goes into the TCP buffer). Each execution adds only one item to the queue at a time.*
- (4) *If the queue is full, a NAK (15) will be returned.*

Set String Format

	ESC	Command ID	Data Block Length	Data	EOT
ASCII	ESC	OE	0001 to 1024	Any legal character (As Data Block Length)	EOT
HEX	1B	4F45	30303031 to 31303234	Any legal character (As Data Block Length)	04

Data Block Length: Four Bytes that specify the length of the data block.
Range: 0001 to 1024 (30303031 to 31303234)

Data: The data without start and end characters. The number of characters depends on the "Data Block Length" value.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Clear String Format

	ESC	Command ID	Clear Command	Data	EOT
ASCII	ESC	OE	0000	0, 1 or 2	EOT
HEX	1B	4F45	30303030	30, 31 or 32	04

Clear Command: Four Byte command to clear the queue. Always 0000 (30303030)

Data: One Byte that selects which queue to clear:
 0 (30) = TCP
 1 (31) = RS232
 2 (32) = Historic Queue

Response to Clear

ACK (06) = Positive

or,

NAK (15) = Negative

Set and Response String Examples 1

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will send the data "ABCD" to the printer's FiFo buffer.

Sent to printer: 1B 4F 45 30 30 30 34 41 42 43 44 04

Response from printer: 06

Set and Response String Examples 2

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will clear the printer's RS232 buffer.

Sent to printer: 1B 4F 45 30 30 30 30 31 04

Response from printer: 06

Print Height – 'OH' 4F_h 48_h

This command allows control of the print height as a percentage.

Set String Format

	ESC	Command ID	Print Height %	EOT
ASCII	ESC	OH	055 to 100	EOT
HEX	1B	4F48	303535 to 313030	04

Print Height %: Three Bytes that set the print height %.

055 (303535) = 55%
 060 (303630) = 60%
 065 (303635) = 65%
 070 (303730) = 70%
 075 (303735) = 75%
 080 (303830) = 80%
 085 (303835) = 85%
 090 (303930) = 90%
 095 (303935) = 95%
 100 (313030) = 100%

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	OH	?	EOT
HEX	1B	4F48	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will set the print height to 55%.

Sent to printer: 1B 4F 48 30 35 35 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of a query string sent to an Ax-Series printer and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4F 48 3F 04

Response from printer: 1B 4F 48 30 35 35 04

Store Bitmap – 'OL' 4F_h 4C_h

This command stores a Windows compatible black and white bitmap (not grey scale) in the logo store on the printer. The bitmap can be inserted into a label via the 6D (m) or 78 (x) commands.

Note: The Bitmap must be 2 colour black and white, and conform to the bitmap (.bmp) standard.

Set String Format

	ESC	Command ID	Number of Bitmap Name Characters	Bitmap Name	Bitmap Data	EOT
ASCII	ESC	OC	1 to 5	Any legal characters (As "Number of Bitmap Name Characters" value)	Values of the bitmap in hex. i.e. 0F is sent as 3046.	EOT
HEX	1B	4F4C	31 to 35	Any legal characters (As "Number of Bitmap Name Characters" value)	Values of the bitmap.	04

Number of Bitmap Name Characters: Single Byte that specifies the number of bitmap name characters.
Valid Bytes: 1 to 5 (31 to 35)

Bitmap Name: One to five characters that specify the name of the bitmap. The number of characters depends on the "Number of Bitmap Name Characters" value.
Valid characters: 1 to 9 and A to z (31 to 39 and 41 to 7A)

Bitmap Data: The hex values of the bitmap. Excepted values are from the range 0x30 to 01x39 or 0x41 to 0x46 bitmap data. Maximum number of characters that you can encode is 2048. A 219x32 bitmap is 2016 bytes.

To work out the Bitmap Data, refer to the example below which shows the hex values for each byte of a 16x16 logo named lmg.bmp.

Each byte is represented by a Hex value as circled. The value circled is 42 but we need to break this down to two Bytes 4 and 2. Each of these Bytes must be sent down as a hex values, so 42 becomes 3432. When 3432 enters the printer it is stored back as 42.

3432

```

424D 7E00 0000 0000 0000 3E00 0000 2800 0000 1000
0000 1000 0000 0100 0100 0000 0000 4000 0000 130B
0000 130B 0000 0200 0000 0200 0000 0000 0000 FFFF
FFFF 18FF 0000 3CFF 0000 BDF7 0000 BDF7 0000 BDF7
0000 BBF7 0000 C3F7 0000 DBF7 0000 DB80 0000 D3F7
0000 D7F7 0000 D7F7 0000 D7F7 0000 D7F7 0000 EFF7
0000 EFFF 0000
    
```


Store Label with variable length name – 'OM' 4F_h 4D_h

This command allows labels with a variable length label name to be sent to the printer's label store and stored with that name. The command also allows the label to be queried.

Note: Similar to the 'S' command (53_h). If the newly saved label (e.g. 001) has the same name as the current label online (e.g. 001), on successfully saving the label, it will be reloaded online again. Any amendments to the label will take effect immediately online.

Set String Format

	ESC	Command ID	Length of Label Name	Label Name	Label Data	EOT
ASCII	ESC	OM	01 to 50	Any legal characters (As "Length of Label Name" value).	Any legal characters	EOT
HEX	1B	4F4D	3031 to 3530	Any legal characters (As "Length of Label Name" value).	Any legal characters	04

Length of Label Name: Two Bytes that specify the number of label name characters.
Valid Bytes: 01 to 50 (3031 to 3530)

Label Name: Characters that specify the name of the label. The number of characters depends on the "Length of Label Name" value.
Valid characters: 1 to 9 and A to z (31 to 39 and 41 to 7A)

Label Data: Label data characters.
Valid characters: 1 to 9 and A to z (31 to 39 and 41 to 7A)

Set String Example

	ESC	Command ID	Length of Label Name		Label Name					Label Data				EOT
ASCII	ESC	OM	0	5	B	E	A	N	S	A	B	C	D	EOT
HEX	1B	4F4D	30	35	42	45	41	4E	53	41	42	43	44	04

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Length of Label Name	Label Name	Query Command	EOT
ASCII	ESC	OM	01 to 50	Any legal characters (As "Length of Label Name" value).	?	EOT
HEX	1B	4F4D	3031 to 3530	Any legal characters (As "Length of Label Name" value).	3F	04

Length of Label Name: Two Bytes that specify the number of label name characters.
Valid Bytes: 01 to 50 (3031 to 3530)

Label Name: Characters that specify the name of the label. The number of characters depends on the "Length of Label Name" value.
Valid characters: 1 to 9 and A to z (31 to 39 and 41 to 7A)

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer and the printer's response.

The string sent to the printer in the example below will save a label named "BEANS" that contains a text element with the data "ABCD" in the printer's label store.

Sent to printer: 1B 4F 4D 30 35 42 45 41 4E 53 41 42 43 44 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of a query string sent to an Ax-Series printer and the printer's response.

The query string below will request the data from a label named "001" in the printer's label store.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4F 4D 30 33 30 30 31 3F 04

Response from printer: 1B 4F 4D 30 33 30 30 31 41 42 43 04

Retrieve a Label with a Variable Length Name from the Label Store and put Online – 'ON' 4F_h 4E_h

This command is used to get a label with a variable length name and put it on-line for printing.

Set String Format

	ESC	Command ID	Head Select	Length of Label Name	Label Name	EOT
ASCII	ESC	ON	1	01 to 50	Any legal characters (As "Length of Label Name" value).	EOT
HEX	1B	4F4E	31	3031 to 3530	Any legal characters (As "Length of Label Name" value).	04

Head Select: 1 Byte print head selection. This is always 1 (31) for an Ax-Series printer.

Length of Label Name: Two Bytes that specify the number of label name characters.
Valid Bytes: 01 to 50 (3031 to 3530)

Label Name Characters that specify the name of the label. The number of characters depends on the "Length of Label Name" value.
Valid characters: 1 to 9 and A to z (31 to 39 and 41 to 7A)

Set String Example

	ESC	Command ID	Head Select	Length of Label Name		Label Name					EOT
ASCII	ESC	ON	1	0	5	B	E	A	N	S	EOT
HEX	1B	4F4E	31	30	35	42	45	41	4E	53	04

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Head Select	Query Command	EOT
ASCII	ESC	ON	1	?	EOT
HEX	1B	4F4E	31	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

The string sent to the printer in the example below will retrieve a label named "ETHENET" from the printer's label store and put it online ready for printing.

Sent to printer: 1B 4F 4E 31 30 37 45 54 48 45 4E 45 54 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of a query string sent to an Ax-Series printer, and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4F 4E 31 3F 04

Response from printer: 1B 4F 4E 31 30 30 04

Configure FiFo Buffer to Receive External Data – 'OP' 4F_h 50_h

The following extended command can be used to configure the FiFo Buffer on the printer.

Set String Format

	ESC	Command ID	Start Character	External Data Encoding	End Character
ASCII	ESC	OP	02 or FF	0 or 1	03 or FF
HEX	1B	4F50	3032 or 4646	30 or 31	3033 or 4646

Length of External Data Block	ACK/NAK Setup	Historic Log Setup	Duplicate Packet Setup
0001 to 1024	0 or 1	0 or 1	00 to 10
30303031 to 31303234	30 or 31	30 or 31	3030 to 3130

Action for Historic Log Full	Historic Log Persistence	Action for Data when Label is Changed	EOT
0 or 1	0 or 1	0 or 1	EOT
30 or 31	30 or 31	30 or 31	04

Start Character: Two Byte start character.
 02 (3032) = STX
 FF (4646) = No start character

External Data Encoding: One Byte character.
 0 (30) = ASCII
 1 (31) = Unicode

End Character: Two Byte end character.
 03 (3033) = ETX
 FF (4646) = No end character

Length of External Data Block: Four characters used to define the length of the external data block if no start and end characters are defined. Maximum length is 1042 bytes.
 Valid characters: 0001 to 1042 (30303031 to 31303432)

ACK/NAK Setup: One Byte character to enable or disable positive/negative acknowledgement given when data is received. Some external devices do not like anything returned from the printer.
 0 (30) = Disable ACK/NAK
 1 (31) = Enable ACK/NAK

- Historic Log Setup: One Byte character to enable or disable writing of packet data to the historic log. The historic log can hold up to 1000 entries.
 0 (30) = Do not write each packet of data to the historic log.
 1 (31) = Write each packet of data to the historic log.
- Duplicate Packet Setup: Two Bytes that define the number of duplicate packets allowed before an alert is set. Each packet is checked against the entries in the historic log.
 00 (3030) = Any duplicates in the last 1000 packets will raise an alert.
 10 (3130) = 10 duplicates can occur before an alert is raised.
- Action for historic log full: One Byte that defines what action occurs when the historic log is full (1000 entries).
 0 (30) = Overwrite entries in the historic log after 1000 entries.
 1 (31) = Clear historic log after 1000 entries and start again.
- Historic Log Persistence: One Byte that defines what happens to the historic log when the printer is shut down.
 0 (30) = Clear historic log on printer shut down.
 1 (31) = Save historic log on printer shut down.
- Action for Data when Label is Changed: One Byte that defines what action occurs when the label is changed.
 0 (30) = Keep data in the external data queue when the label changes.
 1 (31) = Clear data in the external data queue when the label changes.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	OP	?	EOT
HEX	1B	4F50	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

Sent to printer: 1B 4F 50 30 32 30 30 33 31 30 32 34 31 30 30 30 30 30 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of a query string sent to an Ax-Series printer, and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4F 50 3F 04

Response from printer: 1B 4F 50 30 32 30 30 33 31 30 32 34 31 30 30 31 30 30 30 04

Download Label without Save – 'OQ' 4F_h 51_h

This command will allow labels to be downloaded directly to the SGB. A three digit number is required for the SGB to reference this label however it is *not* stored in the label store.

Set String Format

	ESC	Command ID	Label Slot Number	Label Data	EOT
ASCII	ESC	OQ	001 to 255	Any legal characters.	EOT
HEX	1B	4F51	303031 to 323535	Any legal characters.	04

Label Slot Number: Three Byte label reference number. Normally set to 001 (303031) only, but can be set between 001 and 255 (303031 and 323535).

Label Data: Label data characters.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

Note: The label slot number is always set to 000 (303030) as this is the currently printing label. A query to anything other than a label with slot number 000 will bring back the contents from that label in the label store.

	ESC	Command ID	Label Slot Number	Command ID	EOT
ASCII	ESC	OQ	000	?	EOT
HEX	1B	4F51	303030	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

Sent to printer: 1B 4F 51 30 30 31 41 42 43 44 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of a query string sent to an Ax-Series printer, and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4F 51 30 30 30 3F 04

Response from printer: 1B 4F 30 30 30 30 30 41 42 43 04

Sequence Ink Jet on and off – 'OS' 4F_h 53_h

This command allows the user to remotely sequence the printer's ink jet on and off. This does not switch the printer on or off. If the printer is off, i.e. no electric power supplied to it, then this command, like any other, will not work.

Set String Format

	ESC	Command ID	State	EOT
ASCII	ESC	OS	0 or 1	EOT
HEX	1B	4F53	30 or 31	04

State: One Byte to sequence the ink jet on or off.
 0 (30) = Sequence ink jet off (Standby)
 1 (31) = Sequence ink jet on (Ready to print)

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	OS	?	EOT
HEX	1B	4F53	3F	04

Response to Query

	ESC	Command ID	State	Jet Status	EOT
ASCII	ESC	OS	0 or 1	D007 to DB07	EOT
HEX	1B	4F53	30 or 31	D007 to DB07	04

State: One Byte to sequence the ink jet on or off.
 0 (30) = Sequence ink jet off (Standby)
 1 (31) = Sequence ink jet on (Ready to print)

Jet Status: Two hex characters that show the ink jet status.

- D007 = Beginning
- D107 = No Status
- D207 = Printing Disabled
- D307 = Ready to Print
- D407 = Sequencing On
- D507 = Sequencing Off
- D607 = Heating
- D707 = Head Flushed
- D807 = Jet Running
- D907 = Modulating
- DA07 = Phase Locked
- DB07 = Ink On but Jet Off
- DC07 = Jet On But Modulation Off
- DD07 = Jet On But HV Off
- DE07 = Jet On but Modulation Off
- DF07 = Bleeding Head
- E007 = Wakeup Cycle On
- E107 = Standby
- E207 = Manual
- E307 = Fault
- E407 = Recovering
- E507 = Wakeup Cycle Off
- E607 = Off
- E707 = Initialising
- E807 = Booted
- E907 = Not Detected
- EA07 = Undefined
- EB07 = Fault Recovery
- EC07 = Null State
- ED07 = END

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

The string sent to the printer in the example below will sequence the ink jet off.

Sent to printer: 1B 4F 53 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of a query string sent to an Ax-Series printer, and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4F 53 3F 04

Response from printer: 1B 4F 53 30 E3 07 04

External Data Queue Expired Entries Config – 'OV' 4F_h 56_h

This command specifies the printer's behaviour when the external data queue expires.

Set String Format

	ESC	Command ID	Transport Stream	Expired Entry State	Expiry Time
ASCII	ESC	OV	1 or 0	1 or 0	0000 to 2359
HEX	1B	4F56	31 or 30	31 or 30	30303030 to 32333539

Store Expired Entry ID State	ID Length	EOT
1 or 0	00 to 99	EOT
31 or 30	3030 to 99	04

Transport Stream: One Byte that specifies the transport stream.
 1 (31) = Ethernet
 0 (30) = RS232

Expired Entry State: One Byte that specifies the expired entry state.
 1 (31) = True
 0 (30) = False

Expiry Time: Four Bytes that specify the expiry time.
 Valid Characters: 0000 to 2359 (30303030 to 32333539)

Store Expired Entry ID State: 1 Byte to specifies the expired entry ID state.
 1 (31) = True
 0 (30) = False

ID Length: Two Bytes that specify the data ID length.

Response to Set

ACK (06) = Positive

or,

NAK (15) = Negative

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	OP	?	EOT
HEX	1B	4F50	3F	04

Response to Query

Same as set string format with current values.

Set and Response String Examples

The HEX strings below illustrate an example of a set string sent to an Ax-Series printer, and the printer's response.

Sent to printer: 1B 4F 56 31 31 31 30 33 30 31 31 30 04

Response from printer: 06

Query and Response String Examples

The HEX strings below illustrate an example of a query string sent to an Ax-Series printer, and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B 4F 56 31 3F 04

Response from printer: 1B 4F 56 31 31 31 30 33 30 31 31 30 04

Get Current Status – 'O1' 4F_h 31_h

This command is used to query the status of the printer and the condition of the printer cabinet LEDs.

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	O1	?	EOT
HEX	1B	4F31	3F	04

Response to Query

	ESC	Command ID	Status Value	State of LEDs	EOT
ASCII	ESC	O1	000 to 255	00 to 40	EOT
HEX	1B	4F31	303030 to 323535	3030 to 3430	04

Status Value: Three Bytes that identify the printer's status.

See ["Alert Status Table" on page 9-27](#).

Range: 000 to 255 (303030 to 323535)

Note: For Ax-Series printers, if 000 (303030) is returned, the active alert may not be mapped to an Alert ID in Codenet yet. This is for backwards compatibility with other Domino printers that use different alert codes.

State of LEDs: Two Bytes that identify the state of the LEDs.

00 (3030) = Green (ink jet on/off) ON

02 (3032) = Amber On

04 (3034) = Red ON

08 (3038) = Not Used

10 (3130) = Green (ink jet on/off) Flashing

20 (3230) = Amber Flashing

40 (3430) = Red Flashing

80 (3830) = Not Used

Query and Response String Examples

The HEX strings below illustrate an example of a query string sent to an Ax-Series printer, and the printer's response.

Note: The response from your printer may be different to the response illustrated in the example below.

Sent to printer: 1B4F313F04

Response from printer: 1B4F31303131303404

Get Current Alert – 'O2' 4F_h 32_h

This command will get the current list of active alerts.

Query String Format

	ESC	Command ID	Query Command	EOT
ASCII	ESC	O2	?	EOT
HEX	1B	4F32	3F	04

Response to Query

	ESC	Command ID	Number of Active Alerts	ID of Active Alert	Status of Alert	EOT
ASCII	ESC	O2	00 to 16	000 to 999	0 to 1	EOT
HEX	1B	4F32	3030 to 3136	303030 to 393939	30 to 31	04

Note: There will be “Number of active alerts” pairs of “ID of active alert” and “Status of alert”, each representing an active alert.

Number of Active Alerts: Two Bytes that identify the number of active alerts.
Range: 00 to 16 (3030 to 3136)

ID of Active Alert: Three Bytes that identify the alert.
[See “Alert Status Table” on page 9-27.](#)
Range: 000 to 999 (303030 to 393939)

Note: For Ax-Series printers, If 000 (303030) is returned, the active alert may not be mapped to an Alert ID in Codenet yet. This is for backwards compatibility with other Domino printers that use different alert codes.

Status of Alert: One byte to identify the status of the alert.
0 (30) = Not Accepted
1 (31) = Accepted

Query and Response String Examples

The HEX strings below illustrate an example of a query string sent to an Ax-Series printer, and the printer's response.

Sent to printer: 1B 4F 32 3F 04

Response from printer: 1B 4F 32 30 32 31 36 31 30 33 36 31 04

In this example, the "Number of Active Alerts" value is 3032 (02), meaning there are 2 alerts.

Alert 1: The "ID of Active Alert" is 303136 (016) which is ALERT_VENTILATION_STOPPED. The "Status of Alert" is 31 (1) which means the alert has been cleared.

Alert 2: The "ID of Active Alert" is 303336 (036) which is ALERT_INK_LOW. The "Status of Alert" is 31 (1) which means the alert has been cleared.

Alert Status Table

Note: For Ax-Series printers, If 000 (303030) is returned, the active alert may not be mapped to an Alert ID in Codenet yet. This is for backwards compatibility with other Domino printers that use different alert codes.

ASCII	HEX	Alert Name
000	303030	ALERT_NO_ALERT
001	303031	STATUS_READY
002	303032	STATUS_SEQUENCING_ON
003	303033	STATUS_SEQUENCING_OFF
004	303034	STATUS_INK_ON_JET_OFF
005	303035	STATUS_JET_ON_MOD_OFF
006	303036	STATUS_JET_ON_HV_OFF
007	303037	STATUS_BLEEDING_HEAD
008	303038	STATUS_JET_ON_MODN_RST
009	303039	STATUS_STANDBY
010	303130	STATUS_MANUAL
011	303131	STATUS_FAULT
012	303132	STATUS_INITIALISING
013	303133	STATUS_UNDEFINED
014	303134	ALERT_NULL_STATE
015	303135	ALERT_CAB_OVERHEATED
016	303136	ALERT_VENTILATION_STOPPED
017	303137	ALERT_PE_CFG_ERROR
018	303138	ALERT_MC_MODULATION_FAILED
019	303139	ALERT_MC_LOW_BREAK_OFF
020	303230	ALERT_MC_HIGH_BREAK_OFF
021	303231	ALERT_DCM_LATE_STROKES
022	303232	ALERT_DCM_SPEED_LIMIT
023	303233	ALERT_PC_CHRG_DET_FAILED
024	303234	ALERT_PC_CHRG_DET_FAILED
025	303235	
026	303236	ALERT_PC_LATE_PHASING
027	303237	ALERT_PC_PRINT_NOT_DETECTED

EXTENDED CODENET COMMANDS

ASCII	HEX	Alert Name
028	303238	ALERT_HVC_HV_TRIPPED
029	303239	
030	303330	
031	303331	
032	303332	ALERT_VISCOSITY_OUT_OF_RANGE
033	303333	ALERT_VISCOMETER_FAULT
034	303334	ALERT_FLUSH_LOW
035	303335	
036	303336	ALERT_INK_LOW
037	303337	ALERT_SUMP_EMPTY
038	303338	ALERT_SUMP_WARNING1
039	303339	ALERT_SUMP_WARNING2
040	303430	ALERT_SUMP_EXPIRED
041	303431	ALERT_GUTTER_DRY
042	303432	ALERT_MAKEUP_LOW
043	303433	ALERT_GUNBODY_TEMP_HIGH
044	303434	ALERT_GUNBODY_TEMP_LOW
045	303435	ALERT_INVALID_RASTER_FILE
046	303436	ALERT_INVALID_FONT_FILE
047	303437	ALERT_NO_UPDATE_LABEL
048	303438	ALERT_NO_SELECT_LABEL
049	303439	ALERT_NO_CLR_QUEUE_LABEL
050	303530	ALERT_DATA_LATE
051	303531	ALERT_NO_DATA
052	303532	ALERT_PREMATURE_LABEL
053	303533	ALERT_LABEL_ERROR
054	303534	ALERT_LABEL_TO_CODENET
055	303535	
056	303536	
057	303537	ALERT_PREMATURE_END
058	303538	ALERT_SGB_RUNNING
059	303539	ALERT_QUEUE_FULL

EXTENDED CODENET COMMANDS

ASCII	HEX	Alert Name
060	303830	
061	303631	
062	303632	
063	303633	STATUS_HEAD_FLUSHED
064	303634	STATUS_JET_RUNNING
065	303635	STATUS_PHASE_LOCKED
066	303636	STATUS_MODULATING
067	303637	ALERT_INK_HIGH
068	303638	
069	303639	STATUS_HEATING
070	303730	ALERT_HEATING_TIMED_OUT
071	303731	STATUS_RECOVERING
072	303732	STATUS_OFF
073	303733	STATUS_PRINTING_DISABLED
074	303734	ALERT_PE_STANDBY_EXPIRED
075	303735	ALERT_PE_INK_LIFE_ALTERED
076	303736	ALERT_WATCHDOG_RESET
077	303737	ALERT_MAKEUP_HIGH
078	303738	ALERT_PRESSURE_HIGH
079	303739	ALERT_PRESSURE_LOW
080	303830	ALERT_PRESSURE_OOR
081	303831	ALERT_VACUUM_OOR
082	303832	ALERT_PROG_DROPCTRL_FLASH
083	303833	
084	303834	
085	303835	
086	303836	ALERT_MC_MODN_FALL_BACK
087	303837	ALERT_MAKEUP_EMPTY
088	303838	ALERT_SUMP_WARNING1
089	303839	ALERT_SUMP_WARNING2
090	303930	ALERT_SUMP_REMIND_EXPIRY
091	303931	

EXTENDED CODENET COMMANDS

ASCII	HEX	Alert Name
092	303932	ALERT_RESVR_CHANGE_OK
093	303933	ALERT_EXPIRED_INK
094	303934	ALERT_UNKNOWN_INK
095	303935	ALERT_ALREADY_USED
096	303936	ALERT_INK_LIFE_CHANGE
097	303937	ALERT_WRONG_INK
098	303938	Was ALERT_PCB_BATTERY_LOW
099	303939	ALERT_PEC_CFG_CHG
100	313030	ALERT_PEC_BLD_CHG
101	313031	ALERT_PUMPSPEED_OUT_OF_BAND
102	313032	ALERT_PUMPSPEED_HIGH
103	313033	ALERT_PUMPSPEED_LOW
104	313034	ALERT_INK_TEMP_LOW
105	313035	ALERT_INK_TEMP_HIGH
106	313036	ALERT_ADC_FAIL_PRESS
107	313037	ALERT_ADC_FAIL_SOL_LVL
108	313038	ALERT_ADC_FAIL_INK_LVL
109	313039	ALERT_ADC_FAIL_INK_TMP
110	313130	ALERT_ADC_FAIL_HD_TMP
111	313131	ALERT_ADC_FAIL_CAB_TMP
112	313132	ALERT_DATA_ERROR
113	313133	STATUS_WAKEUP_ON
114	313134	STATUS_WAKEUP_OFF
115	313135	ALERT_BLEEDING_DAMPER